

NO. OF COPIES RECEIVED	5
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

RECEIVED
NEW MEXICO OIL CONSERVATION COMMISSION
APR 21 1982
O. C. D.
ARTESIA, OFFICE

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No. Fee Lease

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT --" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- Dry Hole	7. Unit Agreement Name:
2. Name of Operator McClellan Oil Corporation /	8. Farm or Lease Name Jack L
3. Address of Operator P.O. Drawer 730, Roswell, NM	9. Well No. 2
4. Location of Well UNIT LETTER <u>M</u> , <u>860</u> FEET FROM THE <u>South</u> LINE AND <u>560</u> FEET FROM THE <u>West</u> LINE, SECTION <u>14</u> TOWNSHIP <u>6-S</u> RANGE <u>27-E</u> NMPM.	10. Field and Pool, or Wildcat Wildcat
15. Elevation (Show whether DF, RT, GR, etc.) 4106 G.L.	12. County Chaves

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work, SEE RULE 1103.

This test was perforated from 5017-5026.

Propose to P&A this test in the following manner:

1. Shoot off 7" casing at 4000' and pull 7" from 4000' to surface.
2. Set 100' plug across perms from 5026-4926'.
3. Set 100' plug inside and out of 7" stub at 4000'.
4. Set 100' plug at 2570' across Glorieta.
5. Set 100' plug inside and out of 9-5/8" casing at 1454'.
6. Set 10 sack plug at surface.

Heavy mud will be placed between all plugs.

Set a dry hole marker.

Location and pits cleaned and leveled and restored as near as possible to original condition.

1* Set 100' plug e. liner top 4400-4500'

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Paul Rayblake</u>	TITLE <u>Operations Manager</u>	DATE <u>4/20/82</u>
APPROVED BY <u>Mike Wilho</u>	TITLE <u>OIL AND GAS INSPECTOR</u>	DATE <u>APR 23 1982</u>
CONDITIONS OF APPROVAL, IF ANY: 1* as noted above		
Notify N.M.O.C.C. in sufficient time to witness <u>Plugging</u>		