

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)

1. oil well ☐ gas well ☒ other ☐
2. NAME OF OPERATOR
Mesa Petroleum Co.
3. ADDRESS OF OPERATOR
P. O. Box 2009 / Amarillo, TX 79189
4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)
AT SURFACE: 2000' FNL & 2475' FWL
AT TOP PROD. INTERVAL: Same
AT TOTAL DEPTH: Same
16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO: SUBSEQUENT REPORT OF:

TEST WATER SHUT-OFF	<input type="checkbox"/>	<input type="checkbox"/>
FRACTURE TREAT	<input type="checkbox"/>	<input type="checkbox"/>
SHOOT OR ACIDIZE	<input type="checkbox"/>	<input type="checkbox"/>
REPAIR WELL	<input type="checkbox"/>	<input type="checkbox"/>
PULL OR ALTER CASING	<input type="checkbox"/>	<input type="checkbox"/>
MULTIPLE COMPLETE	<input type="checkbox"/>	<input type="checkbox"/>
CHANGE ZONES	<input type="checkbox"/>	<input type="checkbox"/>
ABANDON*	<input checked="" type="checkbox"/>	<input type="checkbox"/>
(other)	<input type="checkbox"/>	<input type="checkbox"/>

5. LEASE
NM-36652
6. IF INDIAN, ALLOTTEE OR TRIBE NAME
7. UNIT AGREEMENT NAME RECEIVED BY
8. FARM OR LEASE NAME SEP 14 1983
Barn Federal
9. WELL NO.
2
10. FIELD OR WILDCAT NAME
West Pecos Slope Abo
11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA
SEC 12, T8S, R22E
12. COUNTY OR PARISH
Chaves
13. STATE
New Mexico
14. API NO.
15. ELEVATIONS (SHOW DF, KDB, AND WD)
4154.0' GR

(NOTE: Report results of multiple completion or zone change on Form 9-330.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Propose to plug and abandon subject well as follows:

1. Set CIBP @ 2795' w/ 35' cmt (Abo perms 2842' - 2925').
2. Set 25 sx plug from 1295' to 1195' (8 5/8" @ 1245').
3. Set 10 sx plug from 150' to surface.
4. Install Dry Hole marker.

MIDLAND, ROSWELL, PARTNERS

XC: BLM-R(O+6), CEN RCDS, ACCTG, MAT CONT, RES ENG, GAS CONT, PROD RCDS(FILE),

Subsurface Safety Valve: Manu. and Type _____ Set @ _____ Ft.

18. I hereby certify that the foregoing is true and correct Regulatory

SIGNED P. S. Math TITLE Coordinator DATE 8-8-83

APPROVED

(This space for Federal or State office use)

APPROVED BY (Orig. Sgd.) PETER W. CHESTER TITLE _____

DATE _____

CONDITIONS OF APPROVAL, IF ANY:

SEP 13 1983

*See Instructions on Reverse Side