

DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPL. (Other instructions on reverse side)

Form approved.
Budget Bureau No. 1004-0135
Expires August 31, 1985

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use "APPLICATION FOR PERMIT" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR
Stevens Operating Corporation

3. ADDRESS OF OPERATOR
P.O. Box 2408, Roswell, NM 88201

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.)
At surface
330 FEL, 1980 FSL

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, OR, etc.)
3954.6GR

5. LEASE DESIGNATION AND SERIAL NO.
NM-27794

6. IF INDIAN, ALLOTTEE OR TRIBE NAME
N/A

7. UNIT AGREEMENT NAME
N/A

8. FARM OR LEASE NAME
Sorenson Federal

9. WELL NO.
#2

10. FIELD AND POOL, OR WILDCAT
Wildcat-San Andres

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA
Sec. 18, T7S, R27E

12. COUNTY OR PARISH
Chaves

13. STATE
NM

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
TEST WATER SHUT-OFF	<input type="checkbox"/>	WATER SHUT-OFF	<input type="checkbox"/>
FRACTURE TREAT	<input type="checkbox"/>	FRACTURE TREATMENT	<input type="checkbox"/>
SHOOT OR ACIDIZE	<input type="checkbox"/>	SHOOTING OR ACIDIZING	<input type="checkbox"/>
REPAIR WELL	<input type="checkbox"/>	(Other)	<input type="checkbox"/>
PULL OR ALTER CASING	<input type="checkbox"/>	REPAIRING WELL	<input type="checkbox"/>
MULTIPLE COMPLETE	<input type="checkbox"/>	ALTERING CASING	<input type="checkbox"/>
ABANDON* Plug	<input checked="" type="checkbox"/>	ABANDONMENT*	<input type="checkbox"/>
CHANGE PLANS	<input type="checkbox"/>		

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.) *

We propose to set @ 4 1/2" CIBP @ 1750' w/ a 35' cement plug. Find Free Point on casing and pull out of hole. Load the hole with 25 sacks (50#) of gel per 100 Bbls of water. Run a cement plug 50' below and above the 4 1/2" stub. * Tag the cement top, Set 10' cement surface plug, set dry hole marker.

* There needs to be a cement plug across 8 7/8" casing shoe, 343'-243'.
Peter W. Chester



18. I hereby certify that the foregoing is true and correct

SIGNED John E. White TITLE Production Manager DATE 5-18-87

(This space for Federal or State office use)

APPROVED BY _____ TITLE _____

CONDITIONS OF APPROVAL, IF ANY:

APPROVED
PETER W. CHESTER

MAY 29 1987

BUREAU OF LAND MANAGEMENT
ROSWELL RESOURCE AREA

*See Instructions on Reverse Side