

UNITED STATES

NM OIL CONSERVATION COMMISSION
SUBMIT IN TRM
Instruction, a re-
verse side
Artesia, NM 88210

Form approved.
Budget Bureau No. 1004-0135
Expires August 31, 1985

c/sf

RECEIVED BY JAN 16 1985 SUNDY NOTICES AND REPORTS ON WELLS (Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use "APPLICATION FOR PERMIT—" for such proposals.)		DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT	
1. O. C. D. ARTESIA, NM <input type="checkbox"/> OTHER P&A		5. LEASE DESIGNATION AND SERIAL NO. NM 20363	
2. NAME OF OPERATOR Yates Petroleum Corporation		6. IF INDIAN, ALLOTTEE OR TRIBE NAME	
3. ADDRESS OF OPERATOR 207 South 4th St., Artesia, NM 88210		7. UNIT AGREEMENT NAME	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 2310 FNL & 330 FEL, Sec. 24-T7S-R29E		8. FARM OR LEASE NAME Cleary "ZE" Federal	
14. PERMIT NO.		9. WELL NO. 1	
15. ELEVATIONS (Show whether OF, RT, GR, etc.) 4081' GR		10. FIELD AND POOL, OR WILDCAT Wildcat San Andres	
		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Unit H, Sec. 24-7S-29E	
		12. COUNTY OR PARISH Chaves	
		13. STATE NM	

18. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐

FRACTURE TREAT ☐

SHOOT OR ACIDIZE ☐

REPAIR WELL ☐

(Other) ☐

PULL OR ALTER CASING ☐

MULTIPLE COMPLETE ☐

ABANDON* ☒

CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐

FRACTURE TREATMENT ☐

SHOOTING OR ACIDIZING ☐

(Other) ☐

REPAIRING WELL ☐

ALTERING CASING ☐

ABANDONMENT* ☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.) *

Propose to plug and abandon well as follows:

1. Set CIBP above perfs w/35' cement on top.
2. Cut off 5 1/2" casing at 2315' and lay down.
3. Spot 50 sx cement plug 50' in and 50' out of casing stub.
4. Spot 50 sx cement plug ~~at top of Salt~~ ^{below} at ~~980-8803~~ ^{1100'-1200'}
5. Spot 50 sx cement plug across 8-5/8" casing shoe at 417-317'. Tag plug.
6. Spot 10 sx cement plug at surface w/dry hole marker.
7. Grade and level location, cut all anchors below ground level and haul away all equipment.

Notify BLM, Roswell, 24 hours prior to plugging.

18. I hereby certify that the foregoing is true and correct

SIGNATURE *Janita Goodlett* TITLE Production Supervisor

DATE 12-4-84

(This space for Federal or State office use)

APPROVED BY *PETER W. CHESTER*

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

JAN 15 1985

*See Instructions on Reverse Side