

UNITED STATES DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT  
NM Oil Cons. Commission  
DRAWER 88210  
SUBMIT IN TRIAL  
(Other instruction. on re-  
view 88210)

Form approved.  
Budget Bureau No. 1004-0135  
Expires August 31, 1985

5. LEASE DESIGNATION AND SERIAL NO.

NM-11596

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☐ GAS WELL ☐ OTHER ☒ Dry Hole

2. NAME OF OPERATOR

McClellan Oil Corporation

3. ADDRESS OF OPERATOR

P.O. Drawer 730, Roswell, N.M. 88202

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.  
See also space 17 below.)  
At surface

1980 FSL & 660 FWL

14. PERMIT NO.

15. ELEVATIONS (Show whether DP, RT, GR, etc.)

3686' G.L.

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐

FRACTURE TREAT ☐

SHOOT OR ACIDIZE ☐

REPAIR WELL ☐

(Other) ☐

PULL OR ALTER CASING ☐

MULTIPLE COMPLETE ☐

ABANDON\* ☒

CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐

FRACTURE TREATMENT ☐

SHOOTING OR ACIDIZING ☐

(Other) ☐

REPAIRING WELL ☐

ALTERING CASING ☐

ABANDONMENT\* ☐

(NOTE: Report results of multiple completion on Well  
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

Propose to plug abandon as follows:

Perfs 4060 to 4346, CIBP @ 4390, 8 5/8" set at 916'

1. Run tubing open-ended to  $\pm$  4060. Set 25 sx plug from 3960' to 4060'

2. Set 50 sx plug from 800' to 1000' inside 4 1/2" Csg.

3. Set 10 sx plug at surface. (50' min.)

Note: Heavy mud will be placed between all plugs. No Casing will be pulled.

4. Dry hole marker will be installed and location cleaned and leveled.

\* need plug across Morieta Top (1840'-1740') in and behind casing.

\*\* Plug 1000'-800' needs to be in and behind casing.

18. I hereby certify that the foregoing is true and correct

SIGNED Paul Fagidula

TITLE Operations Manager

DATE 4/18/88

(This space for Federal or State office use)

APPROVED BY \_\_\_\_\_  
CONDITIONS OF APPROVAL, IF ANY:

TITLE \_\_\_\_\_

DATA APPROVED  
PETER W. CHESTER

MAY 18 1988

\*See Instructions on Reverse Side