

N. M. U. S. G. S. COPY  
UNITED STATES  
DEPART. NT OF THE INTERIOR  
GEOLOGICAL SURVEY  
SUBMIT IN TRIPPLICATE\*  
(Other Instru s on re-  
verse side)Form approved.  
Budget Bureau No. 42-R1424.  
5. LEASE DESIGNATION AND SERIAL NO.

NM-068043

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Harris Fed.

9. WELL NO.

3

10. FIELD AND POOL, OR WILDCAT

Wildcat

11. SEC., T., R., M., OR BLK. AND  
SURVEY OR AREASec. 27, T-15-S, R-27-E,  
N.M.P.M.

12. COUNTY OR PARISH

Chaves

13. STATE

New Mexico

## SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT--" for such proposals.)1. OIL WELL ☐ GAS WELL ☒ OTHER

2. NAME OF OPERATOR

Read &amp; Stevens, Inc.

3. ADDRESS OF OPERATOR

P. O. Box 2126, Roswell, New Mexico 88201

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.  
See also space 17 below.)  
At surface

1980' FEL &amp; 660' FSL Sec. 27, T-15-S, R-27-E, N.M.P.M.

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3472.2' GR - 3484' RKB

16.

## Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

## NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other) Plug Back

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON\*

CHANGE PLANS

X

## SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT\*

(NOTE: Report results of multiple completion on Well  
Completion or Recompletion Report and Log form.)17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any  
proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones perti-  
nent to this work.)\*New TD 8840'. On 6-17-76, received verbal permission from Mr. R. L. Beekman, U.S.G.S.,  
Artesia, New Mexico, to plug back well as follows:

1. Circulate hole full of good mud.
2. Set 50 sx. cement plug 8000'-8400'.
3. Set 19 sx. cement plug 7400'-7550'.
4. Cut & pull 5 1/2" casing.
5. Set 35 sx. cement plug 75' in and 75' out of 5 1/2" casing stub.
6. Set 50 sx. cement plug 4950'-5100'.
7. Set 50 sx. cement plug 3450'-3600'.
8. Set 50 sx. cement plug 1600'-1750' across base of 8 5/8" casing.

RECEIVED

JUL 30 1976

U. S. GEOLOGICAL SURVEY  
ARTESIA, NEW MEXICO

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE Agent

DATE 7-29-76

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

\*See Instructions on Reverse Side

D. 648