

UNITED STATES DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

N. M. O. C. C. COPY
SUBMIT IN TRIPLICATE
(Other instructions
reverse side)

Form approved
Budget Bureau No. 42-R1424.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☐ GAS WELL ☐ OTHER ☒ WATER INJECTION 2. NAME OF OPERATOR CONTINENTAL OIL COMPANY 3. ADDRESS OF OPERATOR Box 460, HOBBS, N.M. 88240 4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 990' FSL & 1651' FWL OF SEC. 35 14. PERMIT NO. _____ 15. ELEVATIONS (Show whether DF, RT, GR, etc.) 3655' DF		5. LEASE DESIGNATION AND SERIAL NO. LC 063496 6. IF INDIAN, ALLOTTEE OR TRIBE NAME _____ 7. UNIT AGREEMENT NAME FOREST POOL 8. NAME OR LEASE NAME FOREST POOL UNIT 9. WELL NO. 21 10. FIELD AND POOL, OR WILDCAT SQUARE LAKE G-SH 11. SEC., T., R., M., OR BLM. AND SURVEY OR AREA SEC. 35, T-16S, R-29E 12. COUNTY OR PARISH EDDY 13. STATE N.M.
--	--	--

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
TEST WATER SHUT-OFF ☐	PULL OR ALTER CASING ☐	WATER SHUT-OFF ☐	REPAIRING WELL ☐
FRACTURE TREAT ☐	MULTIPLE COMPLETE ☐	FRACTURE TREATMENT ☐	ALTERING CASING ☐
SHOOT OR ACIDIZE ☐	ABANDON* ☒	SHOOTING OR ACIDIZING ☐	ABANDONMENT* ☐
REPAIR WELL ☐	CHANGE PLANS ☐	(Other) _____	(Other) _____

* (Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

*There are no remaining commercial reserves on this lease. All wells will be plugged; the above named well by the following procedure:
Remove tubing. Run tubing w/cement retainer to set @ 2400'. Squeeze open hole w/200 sks. Class "C" cmt. Will not reverse out any excess. Pull out retainer & spot 25-50 sks. cmt above retainer. Pull tubing to 500' & spot 100 sks plug to stc. Erect Dry Hole marker.
(No casing will be removed.)*

I hereby certify that the foregoing is true and correct

SIGNED <i>[Signature]</i>	TITLE SR ANALYST	DATE 12-10-75
(This space for Federal or State office use)		

APPROVED BY <i>[Signature]</i>	TITLE _____	DATE _____
CONDITIONS OF APPROVAL, IF ANY:		

*See Instructions on Reverse Side

ARTESIA
USGS-5, Partner, File

RECEIVED
DEC 12 1975
U.S. GEOLOGICAL SURVEY
ARTESIA NEW MEXICO