

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	1
FILE	1-
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. E-7254

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Mesa Retailers, Inc.	8. Farm or Lease Name Superior State
3. Address of Operator 510 W. Texas Ave., Artesia, New Mexico	9. Well No. 4
4. Location of Well UNIT LETTER 0 , 990 FEET FROM THE S LINE AND 2310 FEET FROM THE E LINE, SECTION 12 TOWNSHIP 17 S RANGE 28 E NMPM.	10. Field and Pool, or Wildcat Wildest W. Cave SA
15. Elevation (Show whether DF, RT, GR, etc.)	12. County Eddy

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

We propose to plug above well within the next thirty (3) days as follows:

15 sacks cement from bottom of 5" to fill 100' above bottom which will cover all perforations.

Fill hole up to stub of 5" at approximately 1600'. Put cement plug of 5 sacks on top of stub. Fill with mud to 330'. Put plug of cement to 300'. Fill with mud with cement plug on top surface with proper marker. Level surface.

RECEIVED

APR 11 1967

O. G. C.
ARTESIA, OFFICE

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Don Angle	TITLE President	DATE 4/10/67
APPROVED BY R. L. Harnett	TITLE GENERAL INSPECTOR	DATE 4/11/67
CONDITIONS OF APPROVAL, IF ANY:		