

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

**RECEIVED**  
NEW MEXICO OIL CONSERVATION COMMISSION

JUL 9 1971

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease  
State ☒ Fee ☐

5. State Oil & Gas Lease No.  
647

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Atlantic Richfield Company	8. Farm or Lease Name M. Yates
3. Address of Operator P. O. Box 1978, Roswell, New Mexico 88201	9. Well No. 6
4. Location of Well UNIT LETTER L, 1650 FEET FROM THE South LINE AND 990 FEET FROM THE West LINE, SECTION 33 TOWNSHIP 17-S RANGE 28-E NMPM.	10. Field and Pool, or Wildcat Artesia-Grayburg
15. Elevation (Show whether DF, RT, GR, etc.) 3668' GR	12. County Eddy

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

This well produces about 1/2 BOPD & no water. It is no longer economical to produce and no remedial possibilities exist. We propose to P & A as outlined below:

1. Spot 30 sx cement from 1400-1625'.
2. Cut off and recover 5½" casing from free point.
3. Spot 30 sx cement in & out of 5½" stub.
4. Spot 30 sx cement across 8-5/8" shoe @ 680'.
5. Place 10 sx cement in top of well.

8-5/8" casing will remain intact. 9#/gal gel mud will be left between all cement plugs. Dry hole marker will be installed & location cleared & levelled.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED D.D. Butcher TITLE Dist. Drlg. Supervisor DATE 7/7/71

APPROVED BY W. A. Gressett TITLE OIL AND GAS INSPECTOR DATE JUL 21 1971

CONDITIONS OF APPROVAL, IF ANY: