

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

RECEIVED
NEW MEXICO OIL CONSERVATION COMMISSION

JUL 9 1971

U.S.G.S.
APPROPRIATE OFFICE

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. 647
7. Unit Agreement Name
8. Farm or Lease Name M. Yates
9. Well No. 3
10. Field and Pool, or Wildcat Artesia-Grayburg
12. County Eddy

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

OIL WELL ☒ GAS WELL ☐ OTHER- ☐

1. Name of Operator
Atlantic Richfield Company

1. Address of Operator
P. O. Box 1978, Roswell, New Mexico 88201

1. Location of Well
UNIT LETTER P 330 FEET FROM THE South LINE AND 330 FEET FROM
THE East LINE, SECTION 33 TOWNSHIP 17-S RANGE 28-E NMPM.

15. Elevation (Show whether DF, RT, GR, etc.)
3660' GR

6. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

7. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

This well produces 1/2 BOPD, no water, and is no longer economical to produce. No remedial possibilities exist. We propose to P & A as outlined below:

1. Set 30 sx cement from 1955-2055' (7" shoe @ 2005').
2. Cut & pull 7" casing from free point.
3. Set 30 sx cement in & out of 7" stub.
4. Set 30 sx cement across 8 1/4" shoe @ 547'.
5. Put 10 sx cement in top of well.

Leave 9#/gal gel mud between all cement plugs. 8 1/4" casing will remain intact. Dry hole marker will be erected. Location will be cleared & levelled.

8. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED D.D. Sutchers TITLE Dist. Drlg. Supervisor DATE 7/7/71

APPROVED BY W.A. Gressett TITLE INSPECTOR DATE JUL 21 1971

CONDITIONS OF APPROVAL, IF ANY: