

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE  
(Other Instructions)

N.M.O.C.D. COPY

Form approved.  
Budget Bureau No. 42-R1424.

3. LEASE DESIGNATION AND SERIAL NO.

LC-061638

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME RECEIVED

8. FARM OR LEASE NAME  
Brewer AUG 27 1981

9. WELL NO.

11

10. FIELD AND POOL, OR WILDCAT, OFFICE

High Lonesome

11. SEC., T., R., M., OR BLK. AND  
SURVEY OR AREA

Sec. 13, T-16S, R-29E

12. COUNTY OR PARISH 13. STATE

Eddy

New Mexico

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

General American Oil Company of Texas

3. ADDRESS OF OPERATOR

P. O. Box 128, Loco Hills, New Mexico 88255

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.  
See also space 17 below.)

At surface

660' FNL & 1977' FEL

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3745' DF

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

PULL OR ALTER CASING

FRACTURE TREAT

MULTIPLE COMPLETION

SHOOT OR ACIDIZE

ABANDON\*

REPAIR WELL

CHANGE PLANS

(Other)

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

REPAIRING WELL

FRACTURE TREATMENT

ALTERING CASING

SHOOTING OR ACIDIZING

ABANDONMENT\*

(Other)

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

We propose to plug and abandon the above well as follows:

1. Pull tubing.
2. Spot 100' plug from 2129'-2029' to cover open hole section, 2129'-2105'.
3. Perforate 4 holes @ ~~944'~~ 1090', ~~Base of Salt~~ Top of Yates, and squeeze 55 sacks cement into formation.
4. Perforate 4 holes @ ~~400'~~ 465', ~~Top of Salt~~ 125' above, and squeeze 55 sacks cement into formation.
5. Perforate 4 holes @ 350', water zone, and squeeze 55 sacks cement into formation.
6. Set 10 sack surface plug.
7. Erect permanent well marker.

AUG 20 1981

18. I hereby certify that the foregoing is true and correct

SIGNED M. S. Saning

TITLE Engineer

DATE August 18, 1981

(This space for Federal or State office use)

APPROVED BY  
CONDITIONS OF APPROVAL, IF ANY:

TITLE

Change in steps 3 & 4  
See attached general requirements

\*See Instructions on Reverse Side

APPROVED AS AMENDED  
DATE

AUG 25 1981

JAMES A. GILLHAM  
DISTRICT SUPERVISOR



# United States Department of Interior

GEOLOGICAL SURVEY  
South Central Region  
Roswell District  
P.O. Drawer 1857  
Roswell, New Mexico 88202-1857

Re: Permanent Abandonment

Well: No. 11 Brewer

## CONDITIONS OF APPROVAL

1. Plugging operations authorized are subject to the attached "General Requirements for Permanent Abandonment of Wells on Federal Leases".
2. The Artesia office (Telephone (505) 746-9838) is to be notified in sufficient time for a representative to witness all plugging operations.
3. Blowout prevention equipment is required.
4. In addition to normal filling of pits and cleanup of location, additional surface restoration work may be required, i.e. ripping of pad and/or access road, reseeding, etc. We have asked the Bureau of Land Management for the surface restoration requirements for this well and we should be able to furnish you these requirements within 30 days. After plugging the well and before making final clean-up, you should contact this office unless you have already been advised as to what additional surface restoration work is required.