

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPL
(Other instructions
reverse side)

FE-
re-

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

LC 037777(6)

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

APR 14 1976

2. NAME OF OPERATOR

CONTINENTAL OIL COMPANY

O. C. C.
ARTESIA, OFFICE

3. ADDRESS OF OPERATOR

Box 460, HOBBS, N.M. 88240

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)

At surface

330' FSL & 2310' FWL OF SEC. 34

7. UNIT AGREEMENT NAME

FOREST POOL

8. FARM OR LEASE NAME

FOREST POOL UNIT

9. WELL NO.

17

10. FIELD AND POOL, OR WILDCAT

SQUARE LAKE G-5A

11. SEC., T., R., OR BLK. AND
SURVEY OR AREA

Sec. 34, T-16S, R-29E

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3621' DF

12. COUNTY OR PARISH

EDDY

13. STATE

N.M.

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

☐
☐
☐
☐
☐

PULL OR ALTER CASING

☐
☐
☒
☐
☐

FRACTURE TREAT

MULTIPLE COMPLETE

SHOOT OR ACIDIZE

ABANDON*

REPAIR WELL

CHANGE PLANS

(Other)

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

☐
☐
☐
☐
☐

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any
proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones perti-
nent to this work.)

There are no remaining commercial reserves on this
lease. All wells will be P&A; the above named well
by the following procedure:

Run tubing open-ended to 2590'. Spot
Class "C" cement from 2590' to 2000'. Pull tubing to
1200' & WOC. Tag top of plug & if below 2100',
spot additional 50 sks. cement plug. Pull tubing to
500' & spot 100 sks cement plug to surface. Erect dry hole
marker. (No casing will be removed).

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE

SR. ANALYST

DATE

12-10-75

(This space for Federal or State office use)

APPROVED

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

L. L. BEEKING

ACTING DISTRICT ENGINEER

*See Instructions on Reverse Side

11545 (Artesia)-5, Partner, File