

OIL CONS. COMMISSION
Drawer DD
ARTESIAN STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRI. DATE*
(Other instructions on re-verse side)

Form approved,
Budget Bureau No. 42-R1424.

C/SF

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☐ GAS WELL ☐ OTHER <u>WATER INTERSECTION WELL</u>	5. LEASE DESIGNATION AND SERIAL NO. <u>1.0 (21177-2)</u>
2. NAME OF OPERATOR <u>LAYTON ENTERPRISES, INC.</u>	6. IF INDIAN, ALLOTTEE OR TRIBE NAME
3. ADDRESS OF OPERATOR <u>3103 19TH ST. LUBBOCK, TEXAS 79403</u>	7. UNIT AGREEMENT NAME <u>Pool Unit</u>
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface <u>651' FNL 517' FNL</u> <u>35-165-24E</u>	8. FARM OR LEASE NAME <u>FOREST POOL UNIT</u>
14. PERMIT NO.	9. WELL NO. <u>2</u>
15. ELEVATIONS (Show whether DF, RT, OR, etc.) <u>3664 GL</u>	10. FIELD AND POOL, OR WILDCAT <u>SQUARE LAKE GSA</u>
	11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA <u>SEC 25 T16S R29E</u>
	12. COUNTY OR PARISH <u>ELLY</u>
	13. STATE <u>NM</u>

10. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐	PULL OR ALTER CASING ☐
FRACTURE TREAT ☐	MULTIPLE COMPLETE ☐
SHOOT OR ACIDIZE ☐	ABANDON* ☒
REPAIR WELL ☐	CHANGE PLANS ☐
(Other) ☐	

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐	REPAIRING WELL ☐
FRACTURE TREATMENT ☐	ALTERING CASING ☐
SHOOTING OR ACIDIZING ☐	ABANDONMENT* ☐
(Other) ☐	

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

INTEND TO PLUG & ABANDON WELL AS FOLLOWS:

8 5/8" CASING @ 418' w/50 SK CEMENT

5 1/2" CASING @ 2500 w/ 100 SK CEMENT

1. CIRCULATE HOLE WITH MUD LADEN FLUID
2. SPOT 100 SK CEMENT PLUG THRU TUBING @ 2500'
3. PERFORATE 5 1/2" CASING, BELOW SALT SECTION, @ 900'
4. PUMP 300 SK CEMENT THRU 5 1/2" CASING PERFS @ 900'
& CIRCULATE TO SURFACE LEAVING 5 1/2" FULL OF CEMENT
5. SET SURFACE MARKER
6. CLEAR AND LEVEL LOCATION

18. I hereby certify that the foregoing is true and correct

SIGNED Donald L. Layton TITLE PRESIDENT DATE 9-23-53

(This space for Federal or State Use)

APPROVED [Signature] TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY:

DEC 14 1983

*See Instructions on Reverse Side