

N. M. O. C. C. COPY
UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPL
(Other instructions
verse side)Form approved
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

LC 063496

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)1. OIL WELL ☒ GAS WELL ☐ OTHER ☐ RECEIVED

2. NAME OF OPERATOR CONTINENTAL OIL COMPANY APR 14 1976

3. ADDRESS OF OPERATOR Box 460, HOBBS, N.M. 88240

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.
See also space 17 below.) ARTESIA, OFFICE

990' FSL & 520' FWL OF SEC. 35

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, CR, etc.)

3649' DF

7. UNIT AGREEMENT NAME

FOREST POOL

8. FARM OR LEASE NAME

FOREST POOL UNIT

9. WELL NO.

70

10. FIELD AND POOL, OR WILDCAT

SQUARE LAKE G-SH

11. SEC., T., R., M., OR BLE. AND
SURVEY OR AREA

SEC. 35, T-16S, R-29E

12. COUNTY OR PARISH

EDDY

13. STATE

N.M.

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any
proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones perti-
nent to this work.)

There are no remaining commercial reserves on this lease.
All wells will be plugged; the above named well by the
following procedure:

Remove tubing. Run tubing w/cement retainer to set @
2400'. Squeeze open hole w/200 sks. Class "C" cmt.
Will not reverse out any excess. Pull out retainer & spot
25-50 sks. cmt above retainer.

Pull tubing to 500' & spot 100 plug to skt.
Erect Dry Hole marker.

(No casing will be removed.)

I hereby certify that the foregoing is true and correct

SIGNED

TITLE

SR. ANALYST

DATE

12-10-75

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

*See Instructions on Reverse Side

ARTESIA
11565-5. Partner, File