

NO. OF COPIES RECEIVED	2
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

JUL 26 1974

5a. Indicate Type of Lease	State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	

**SUNDRY NOTICES AND REPORTS OF WELLS**

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Mobil Oil Corporation	8. Farm or Lease Name West Henshaw Permian, Unit Tract 14
3. Address of Operator Box 633, Midland, Texas 79701	9. Well No. 1
4. Location of Well UNIT LETTER <u>L</u> , <u>4620</u> FEET FROM THE <u>South</u> LINE AND <u>660</u> FEET FROM THE <u>West</u> LINE, SECTION <u>2</u> TOWNSHIP <u>16-S</u> RANGE <u>30E</u> NMPM.	10. Field and Pool, or Wildcat Henshaw Grayburg West
15. Elevation (Show whether DF, RT, GR, etc.) 3912 DF	12. County Eddy

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Set 100' Cement plug across perforations (2870'-76') 35 Sx.

2. Circulate Hole to mud laden fluid (25 Sx of gel/100 Bbl of water).

\* 3. Set 100' Cement plug from 2150' to 2250 (35Sx) *if 5 1/2" recovered below the point*

4. Cut off 5 1/2" casing and pull & set 100' plug at cut off point.

\* *100' Cement Plug at base of salt*  
5. Set 100 cement plug from 400 to 500'.

6. Set 10 Sx at surface.

7. Erect monument & clear location.

Note: If able to salvage any 5 1/2" casing set 100' cement plug at cut off point.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE Authorized Agent DATE 7-25-74

APPROVED BY [Signature] TITLE OIL AND GAS INSPECTOR DATE JUL 29 1974

CONDITIONS OF APPROVAL, IF ANY: Notify N.M.O.C.C. in sufficient time to witness

\* *as noted above* Plugging operations