

RECEIVED

AUG 16 1984

Form Approved.  
Budget Bureau No. 42-R1424

4SF

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEY

O. C. D.  
ARTESIA, OFFICE

5. LEASE  
NM 0560379  
6. INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)

1. oil ☐ well gas ☐ well other ☒ water injection  
2. NAME OF OPERATOR  
Kay Jay Oil Co. ✓  
3. ADDRESS OF OPERATOR  
P.O. Box 3565 Midland, Texas 79702  
4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)  
AT SURFACE: 672' FSL-1980' FEL-Sec. 8-T16S-R30E  
AT TOP PROD. INTERVAL:  
AT TOTAL DEPTH:

7. UNIT AGREEMENT NAME  
Southwest Henshaw Premier Unit  
8. FARM OR LEASE NAME  
9. WELL NO.  
3  
10. FIELD OR WILDCAT NAME  
West Henshaw Grayburg  
11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA  
Section 8 - T16S - R30E  
12. COUNTY OR PARISH  
Eddy  
13. STATE  
New Mexico  
14. API NO.  
15. ELEVATIONS (SHOW DF, KDB, AND WD)  
3797' GL

16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO:		SUBSEQUENT REPORT OF:
TEST WATER SHUT-OFF	<input type="checkbox"/>	<input type="checkbox"/>
FRACTURE TREAT	<input type="checkbox"/>	<input type="checkbox"/>
SHOOT OR ACIDIZE	<input type="checkbox"/>	<input type="checkbox"/>
REPAIR WELL	<input type="checkbox"/>	<input type="checkbox"/>
PULL OR ALTER CASING	<input type="checkbox"/>	<input type="checkbox"/>
MULTIPLE COMPLETE	<input type="checkbox"/>	<input type="checkbox"/>
CHANGE ZONES	<input type="checkbox"/>	<input type="checkbox"/>
ABANDON*	<input checked="" type="checkbox"/>	<input type="checkbox"/>
(other)		

(NOTE: Report results of multiple completion or zone change on Form 9-330.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

Propose to P & A subject waterflood injection well due to termination of water injection as follows:

1. Set CIBP @ 2650' w/15 sx. cement on top
2. Set 25 sx. cement plug 2110' - 1810' (top of queens)
3. Pump 75 sx. plug through hole in 5½" casing @ 1100'. WOC & Tag
4. Perforate 5½" casing @ 533' and spot 40 sx. plug. WOC & Tag
5. Set 10 sx. surface plug.
6. Install dry hole marker and restore location.

Subsurface Safety Valve: Manu. and Type \_\_\_\_\_ Set @ \_\_\_\_\_ Ft.

18. I hereby certify that the foregoing is true and correct

SIGNED T. D. Huff TITLE Agent DATE 8/15/84

(This space for Federal or State office use)

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_  
CONDITIONS OF APPROVAL, IF ANY: