WM OIL CONS COMMISSION

Drawer DD

Artesia, NM 88210

	FORM APPROVED
	Budget Bureau No. 1004-0135
	Expires: March 31, 1993
-	D 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1

June 1990) DEPARTMEN	TED STATES NT OF THE INTERIOR LAND MANAGEMENT	Budget Bureau No. 1004-0135 Expires: March 31, 1993  5. Lease Designation and Serial No.
Do not use this form for proposals to de	AND REPORTS ON WELLS rill or to deepen or reentry to a different reservoir. PR PERMIT—" for such proposals	NM-04068 6. If Indian, Allottee or Tribe Name
	T IN TRIPLICATE	7. If Unit or CA, Agreement Designation
I. Type of Well  Soil Gas Well Well Other	<b>JAN</b> 11 '95	8. Well Name and No.
Name of Operator     Mack Energy Corporation     Address and Telephone No.	O. C. D.  ARTESIA, OFFICE	Sivley Federal #5  9. API Well No.  30-015-03895
P.O. Box 960, Artesia, NM & Location of Well (Footage, Sec., T., R., M., or Survey D	38211-0960 (505) 748-1288	10. Field and Pool, or Exploratory Area  West Henshaw Grayburg
Unit B 660 FNL 1980 FEL Sec 17-T16S-R30E		11. County or Parish, State
	(s) TO INDICATE NATURE OF NOTICE, REPO	│ Eddy、 № PRT, OR OTHER DATA
TYPE OF SUBMISSION	TYPE OF ACTION	l
X Notice of Intent	Abandonment Recompletion	Change of Plans New Construction
☐ Subsequent Report	Plugging Back Casing Repair	Non-Routine Fracturing Water Shut-Off
L Final Abandonment Notice	Altering Casing    X Other Request TA Status	Conversion to Injection  Dispose Water (Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)
3. Describe Proposed or Completed Operations (Clearly state a	ill pertinent details, and give pertinent dates, including estimated date of starti	ng any proposed work. If well is directionally drilled

đ, 1 give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

Mack Energy requests TA status on the above well. Set cast iron plug 50' above top perf. Pressure test csg. to 500#.

(This space for Federal or State office use)	Title	Production Clerk  PETROLEUM ENGINEER		1/9/95
14. I hereby certify that the foregoing is true and correct Signed August Carte		Production Clark	_	12/14/94

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction

## BUREAU OF LAND MANAGEMENT CARLSBAD RESOURCE AREA

## Temporary Abandonment of Wells on Federal Lands

## Conditions of Approval

According to 43 CFR 3162.3-4-c, " No well may be temporarily abandoned for more than 30 days without the prior approval of the authorized officer".

Temporary Abandonment (TA) status approval requires a successful casing integrity test as follows:

- Contact the appropriate BLM office at least 24 hours prior to the scheduled Casing Integrity Test. For wells in Eddy County call (505) 887-6544; for wells in Lea County call (505) 393-3612.
- A bridge plug or packer shall be set at a maximum of 50 feet above any open perforations or open hole.
- 3. All downhole production/injection equipment (tubing, rods, etc.) shall be removed from the casing if they are not isolated by a packer.
- 4. The production casing shall be filled with corrosion inhibited fluid and pressure tested to 500 psi. The casing shall be capable of holding this pressure for at least 30 minutes with a 10% allowable leak-off.

Wells that successfully pass the casing integrity test will be approved for Temporary Abandonment (TA) status for 12 months provided that the operator:

- Submits a subsequent Sundry Notice requesting TA approval,
- 2. Attaches a clear copy or the original of the pressure test chart,
- 3. And attaches a detailed justification why the well should not be plugged and abandoned.

The TA status could be extended without another casing integrity test provided there was no leak-off during the test.

If the well does not pass the casing integrity test, then the operator shall within 30 days submit to BLM for approval one of the following:

- 1. A procedure to repair the casing so that a TA approval can be granted.
- 2. A procedure to plug and abandon the well.