

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT
NM OIL CONS. COMMISSION
Drawer DD

SUBMIT IN TRIPLICATE
(Other instruct
verse side)

Budget Bureau No. 1004-0135
Expires August 31, 1985

5. LEASE DESIGNATION AND SERIAL NO.

NM 0610

C/SF

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT" for such proposals.)

7. UNIT AGREEMENT NAME

SW Henshaw Premier Unit

8. FARM OR LEASE NAME

9. WELL NO.

14

10. FIELD AND POOL, OR WILDCAT

West Henshaw Grayburg

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Section 18-T16S-R30E

12. COUNTY OR PARISH

Eddy

13. STATE

New Mexico

1. OIL WELL ☐ GAS WELL ☐ OTHER ☒ Water Injection RECEIVED BY

2. NAME OF OPERATOR

Kay Jay Oil Co.

NOV 4 1985

3. ADDRESS OF OPERATOR

P.O. Box 3565 Midland, Texas

797020 C.D.

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.)

See also space 17 below.

At surface

ARTEZIA, OFFICE

660° FSL-660° FEL-Sec.18-T16S-R30E

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3765' DF

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

Propose to P & A subject waterflood injection well due to termination of water injection as follows:

1. Set CIBP @ 2675' w/15 sx. cement of top of plug.
2. Spot 25 sx. plug (1950'-1800') (Top of Queens)
3. Pressure test casing to determine any additional repair plugs.
4. Perforate @ 1200' & spot 45 sx. cement plug (100' inside & 100' outside) WOC & tag plug
5. Perforate @ 475' & spot 45 sx. cement plug (100' inside & 100' outside) WOC & tag plug
6. Set 10 sx. surface plug.
7. Install dry hole marker and restore location.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE

Agent

DATE

7/19/85

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

11-1-85

CONDITIONS OF APPROVAL, IF ANY:

Subject to
Like Approval

*See Instructions on Reverse Side

Title 18, Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.