

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

RECEIVED

NEW MEXICO APPLIED FOR RESERVOIR COMMISSION

O. C. C.
ARTESIA, OFFICE

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. B3006
7. Unit Agreement Name
8. Farm or Lease Name Jackson State
9. Well No. 6
10. Field and Pool, or Wildcat Square Lake
12. County Eddy

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>
2. Name of Operator Newmont Oil Company ✓
3. Address of Operator Box 1305, Artesia, New Mexico
4. Location of Well UNIT LETTER <u>K</u> 1980' FEET FROM THE <u>South</u> LINE AND 1980' FEET FROM THE <u>West</u> LINE, SECTION <u>36</u> TOWNSHIP <u>16S</u> RANGE <u>30E</u> NMPM.
15. Elevation (Show whether DF, RT, GR, etc.)

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- Set 25 sack plug in and out of 7" casing at 2436'.
- Cut and pull 7" casing.
- Set 25 sack plug in and out of 7" stub.
- If more than 1600' of 7" casing is pulled. Place ³⁰/₂₅ sack plug at base of salt @ 1320'.
- Set 30 sack plug ^{in out} at base of 10". avg @ 585
- Cut and pull 10".
- Place marker at surface in ¹⁰/₅ sack cement.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Harmon L. Lott TITLE Divn. Supt. DATE 4/24/72

ROVED BY W. A. Grosse TITLE WILM AND GAS INSPECTOR DATE MAY 4 1972

DITIONS OF APPROVAL, IF ANY:

Notify N.M.O.C.C. in sufficient time to witness

* as noted above Plugging operations