

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

**OIL CONSERVATION DIVISION**  
P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

WELL API NO. 30015048020051
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No.
7. Lease Name or Unit Agreement Name North Square Lake Premier Unit
8. Well No. 18
9. Pool name or Wildcat Square Lake (G/SA) North
10. Elevation (Show whether DF, RKB, RT, GR, etc.)

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	2. Name of Operator Walsh and Watts, Inc.
3. Address of Operator 1111 Seventh Street, Wichita Falls, Texas 76301	4. Well Location Unit Letter <u>W</u> : <u>660</u> Feet From The <u>South</u> Line and <u>1980</u> Feet From The <u>East</u> Line Section <u>5</u> Township <u>16S</u> Range <u>31E</u> NMPM <u>Eddy</u> County

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
<b>NOTICE OF INTENTION TO:</b>	<b>SUBSEQUENT REPORT OF:</b>
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- Preparing to plug and abandon. Procedures should commence April 2, 1995
- 1.) Set CIBP at 3350'±. Cap with 20' cement
  - 2.) Circulate hole with mud. 3'
  - 3.) Perforate at 1900'. Squeeze with 50 sx. cement from 1800' to 1900' **STAG**
  - 4.) Perforate at 1300'. Squeeze with 50 sx. cement from 1200' to 1300'.
  - 5.) Perforate at 285'. Squeeze with 60 sx. cement from 165' to 285' **Tag**
  - 6.) Perforate at 50'. Circulate to surface with 25 sx. cement. Cap with marker.

Note: Well drilled by Leonard Oil Co. as the Humble State E-8633 Well #1 on 7-9-61.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Alfred B. Guinn TITLE Vice-President DATE 3/16/95

TYPE OR PRINT NAME Alfred B. Guinn TELEPHONE NO. 817-723-2104

(This space for State Use)

ORIGINAL SIGNED BY TIM W. GUNN  
DISTRICT II SUPERVISOR

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE MAR 28 1995

CONDITIONS OF APPROVAL, IF ANY: