

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

RECEIVED
SUBMISSION OF
(Other instructions
verse side)
88210

Form approved.
Budget Bureau No. 1004-0135
Expires August 31, 1985

clsf

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. ☐ OIL WELL ☐ GAS WELL ☐ OTHER ☒ dry hole

2. NAME OF OPERATOR
Pool Oil Company, ✓

3. ADDRESS OF OPERATOR
P. O. Box 2837, Roswell, New Mexico, 88201

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface
330' FNL & 660' FEL

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)
4071.5 GR

5. LEASE DESIGNATION AND SERIAL NO.
NM 54424

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME
Ronadero 8 USA

9. WELL NO.
1

10. FIELD AND POOL, OR WILDCAT
N. Sq. Lake-Grbg/SA

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA
Sec. 8, T16S, R31E

12. COUNTY OR PARISH
Eddy

13. STATE
NM

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐ PULL OR ALTER CASING ☐
FRACTURE TREAT ☐ MULTIPLE COMPLETE ☐
SHOOT OR ACIDIZE ☐ ABANDON* ☒
REPAIR WELL ☐ CHANGE PLANE ☐
(Other) ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐ REPAIRING WELL ☐
FRACTURE TREATMENT ☐ ALTERING CASING ☐
SHOOTING OR ACIDIZING ☐ ABANDONMENT* ☐
(Other) ☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

11-3-85 Pool Oil Company intends to plug and abandon this well as follows, per verbal instructions from Mr. Bob Pitsche:

1. Set CIBF @ 3450 w/ 35 feet of cement on top.
2. Spot a 100' cement plug accross the top of the Grayburg formation, 3088' to 3188'.
3. Shoot casing off at approximately 1670'.
4. Set 100' cement plug accross stub, 50' in and 50' out. - Tag
5. Set 100' cement plug accross 8 5/8" shoe, 50' in and 50' out. - Tag
6. Set 50' cement surface plug.
7. Install regulation dry hole marker and clean location.

18. I hereby certify that the foregoing is true and correct

SIGNED Frank L. Pitsche

TITLE Engineer

DATE 11-3-85

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE 1-8-86

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side