

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPLICATE
(Other instructions
verse side)

Budget Bureau No. 1004-0135
Expires August 31, 1985

c/sr

SUNDRY NOTICES AND REPORTS KNOWLEDGE Division

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☐ GAS WELL ☒ OTHER Water Injector Artesia, NM 88210-2834

2. NAME OF OPERATOR Walsh and Watts, Inc.

3. ADDRESS OF OPERATOR 1111 Seventh Street Wichita Falls, Texas 76301

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.
See also space 17 below.)
At surface
Unit letter "D" or 660' from North line & 660' from West line
of Sec. 8, T16S, R31E of NMPM.

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

4016 G.L.

5. LEASE DESIGNATION AND SERIAL NO.

011599 API# 30-015-04821

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME
North Square Lake
Premier Unit

8. FARM OR LEASE NAME

9. WELL NO.

21

10. FIELD AND POOL, OR WILDCAT

Square Lake (G/SA) North

11. SEC., T., R., M., OR BLE. AND
SURVEY OR AREA

D - 08 - 16S - 31E

12. COUNTY OR PARISH 13. STATE

Eddy

New Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

TEST WATER SHUT-OFF ☐ PULL OR ALTER CASING ☐
FRACTURE TREAT ☐ MULTIPLE COMPLETE ☐
SHOOT OR ACIDIZE ☐ ABANDON* ☒
REPAIR WELL ☐ CHANGE PLANE ☐
(Other) ☐

WATER SHUT-OFF ☐ REPAIRING WELL ☐
FRACTURE TREATMENT ☐ ALTERING CASING ☐
SHOOTING OR ACIDIZING ☐ ABANDONMENT* ☐
(Other) ☐

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.) *

Plug and Abandon injector. No longer required in waterflood. Procedures should begin July 19, 1999. Well drilled originally by John H. Trigg as the Federal "PV" Well #5-8.

NOTE: 8-5/8" O.D. set at 682' with 100 sacks (Cement circ. to surface)

4-1/2" O.D. set at 3344' with 200 sacks (Cement top at 2180')

- 1.) Set CIBP at 3250' cap with 35' cement.
- 2.) Circulate hole with mud.
- 3.) Recover 4-1/2" O.D. casing with estimated recovery of 1500'
- 4.) Spot 15 sacks 1800' to 1900'
- 5.) Spot 35 sacks 1200' to 1300'
- 6.) Spot 35 sacks 632' to 732'
- 7.) Spot 104 sacks 0' to 290'

SEE ATTACHED FOR
CONDITIONS OF APPROVAL

18. I hereby certify that the foregoing is true and correct

SIGNED Alexis C. Swoboda TITLE Vice - President

DATE 6/30/99

(This space for Federal or State office use)

(ORIG. SGD.) ALEXIS C. SWOBODA

PETROLEUM ENGINEER

APPROVED BY _____ TITLE _____

DATE JUL 19 1999

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side

RECEIVED

JUL 07 '99

BLM
ROSWELL, NM