

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

NM OIL CONS. COMMISSION
Drawn SUBMIT IN TRIPL
(Other instructions
for use of form) 88210

Form approved.
Budget Bureau No. 43-R1424.

5. LEASE DESIGNATION AND SERIAL NO.
LC-063105

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to an uncompleted reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☐ GAS WELL ☐ OTHER ☒ TA - WIW JUN 1 1982

2. NAME OF OPERATOR

Newmont Oil Company

O. C. D.

3. ADDRESS OF OPERATOR

ARTESIA, OFFICE

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.
See also space 17 below.)
At surface

2080' FNL & 560' FWL of Section 28

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3989' GLM

7. UNIT AGREEMENT NAME

Square Lake Flood (East

8. FARM OR LEASE NAME

Sheldon Federal

9. WELL NO.

3

10. FIELD AND POOL, OR WILDCAT

Square Lake (G. SA)

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

28-16S-31E

12. COUNTY OR PARISH

Eddy

13. STATE

New Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

☐
☐
☐
☐
☐

PULL OR ALTER CASING

☐
☐
☒
☐
☐

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

REPAIR WELL

(Other)

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

☐
☐
☐

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

☐
☐
☐
☐
☐

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

We propose to plug and abandon the above well as follows:

1. Spot 50 sack cement plug across producing interval in cased hole
2. Perforate at base of salt and squeeze with 50 sacks cement leaving 100' plug in casing.
3. Perforate at top of salt and squeeze with 50 sacks cement leaving 100' plug in casing.
4. Set 15 sack cement plug at surface down surface and production casing.
5. Erect permanent well marker.

Note: (a). Your office will be notified 24 hrs. prior to operations.
(b). All plugs will be tagged
(c). Hole will be loaded between all plugs with 10# mud.
(d). We do not plan to pull any casing.

RECEIVED
JUN 11 1982

OIL & GAS
U.S. GEOLOGICAL SURVEY
ROSWELL, NEW MEXICO

18. I hereby certify that the foregoing is true and correct

SIGNED

[Signature]

TITLE

Area Manager

DATE 6/10/82

(This space for Federal or State Approval)

APPROVED

APPROVED BY (Orig. Sgd.) PETER W. CHESTER

CONDITIONS OF APPROVAL, IF ANY:

JUN 17 1982

FOR

JAMES A. GILLHAM
DISTRICT SUPERVISOR

*See Instructions on Reverse Side