

NO. OF COPIES RECEIVED	4
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	2

RECEIVED
NEW MEXICO OIL CONSERVATION COMMISSION

AUG 28 1974

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

O. C. C.
ARTESIA, OFFICE

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>

5. State Oil & Gas Lease No. B-2721

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- Water Injection Well	7. Unit Agreement Name
2. Name of Operator Kennedy Oil Co., Inc.	8. Farm or Lease Name State "C"
3. Address of Operator Box 151 Artesia, New Mexico 88210	9. Well No. 2
4. Location of Well UNIT LETTER A 660 FEET FROM THE North LINE AND 660 FEET FROM THE East LINE, SECTION 32 TOWNSHIP 16S RANGE 31E NMPM.	10. Field and Pool, or Wildcat Square Lake
15. Elevation (Show whether DF, RT, GR, etc.) 3953 DF	12. County Eddy

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to plug and abandon as follows:

Set C.I. bridge plug @ 3150' and cap with 30' cement plug.
Place heavy mud between plugs.
Pull recoverable 5 1/2" csg. above cement top estimated @ 2450'.
Place 100' cement plug @ pipe stub if stub is over 800' below base of salt.
Place 100' cement plug @ base of salt 1578-1678'.
Place 100' cement plug @ top of salt 600-700.
Pull recoverable 8 5/8" csg. and place a 35 sack cement plug in stub.
Place surface plug, clean clear and level location and place regulation marker.
Will advise commission when plugging will commence.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED *P.B. Kennedy* TITLE **President** DATE **8/28/74**

APPROVED BY *W.A. Gressett* TITLE **OIL AND GAS INSPECTOR** DATE **AUG 29 1974**

CONDITIONS OF APPROVAL, IF ANY: **Notify N.M.O.C.C. in sufficient time to witness**

Plugging