

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

RECEIVED
NEW MEXICO OIL CONSERVATION COMMISSION
AUG 16 1972

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

O. C. C.
ARTESIA, OFFICE

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. B-2721

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name East Square Lake
2. Name of Operator Newmont Oil Company	8. Farm or Lease Name State "R"
3. Address of Operator Box 1305, Artesia, New Mexico 88210	9. Well No. 1
4. Location of Well UNIT LETTER <u>D</u> <u>660</u> FEET FROM THE <u>North</u> LINE AND <u>660</u> FEET FROM THE <u>West</u> LINE, SECTION <u>32</u> TOWNSHIP <u>16S</u> RANGE <u>31E</u> NMPM.	10. Field and Pool, or Wildcat Square Lake G. SA.
15. Elevation (Show whether DF, RT, GR, etc.) 3893' G.L.	12. County Eddy

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

We plan to plug this well in the following manner:

- Set ²⁵ sack cement plug in and out of the 5 1/2 " casing shoe @ 3207'.
- Knockoff 5 1/2" casing at lowest possible free point, mud up hole and set 35 sack cement plug in and out of 5 1/2" casing stub. If more than 1600' of 5 1/2" is pulled set 35 sack cement plug at base of salt @ 1485'.
- Mud up hole and set 35 sack cement plug in and out of 8 1/4" casing shoe @ 612'.
- Knockoff 8 1/4" surface casing at lowest possible free point, mud up hole and set marker at surface with a 10 sack cement plug.

We will notify N.M.O.C.C. in sufficient time to witness operations.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>James F. Lutter</u>	TITLE <u>Divn. Supt.</u>	DATE <u>8/14/72</u>
APPROVED BY <u>W. A. Gressett</u>	TITLE <u>OIL AND GAS INSPECTOR</u>	DATE <u>AUG 21 1972</u>
CONDITIONS OF APPROVAL, IF ANY: <u>as noted</u>		