

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

RECEIVED
 NEW MEXICO OIL CONSERVATION COMMISSION
 AUG 16 1972

Form C-103
 Supersedes Old
 C-102 and C-103
 Effective 1-1-65

O. C. C.
 ARTESIA, OFFICE

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. B-2721
7. Unit Agreement Name East Square Lake
8. Farm or Lease Name State "R"
9. Well No. 2
10. Field and Pool, or Wildcat Square Lake G. SA.
12. County Eddy

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
 USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- 2. Name of Operator Newmont Oil Company ✓ 3. Address of Operator Box 1305, Artesia, New Mexico 88210 4. Location of Well UNIT LETTER <u>E</u> <u>1650</u> FEET FROM THE <u>North</u> LINE AND <u>1020</u> FEET FROM THE <u>West</u> LINE, SECTION <u>32</u> TOWNSHIP <u>16S</u> RANGE <u>31E</u> NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 3897' G.L.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

We plan to plug this well in the following manner:

- Set ²⁵ 15 sack cement plug in and out of the 5 1/2" casing shoe @ 3235'.
- Knock off 5 1/2" casing at lowest possible free point, mud up hole and set 35 sack cement plug in and out of 5 1/2" casing stub. If more than 1700' of 5 1/2" is pulled set 35 sack cement plug at base of salt @ 1540'.
- Mud up hole and set 35 sack cement plug in and out of 8 1/4" casing shoe @ 580'.
- Knock off 8 1/4" casing at lowest possible free point, mud up hole and set marker at surface with a 10 sack cement plug.

We will notify N.M.O.C.C. in sufficient time to witness operations.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED German L. Ledbetter TITLE Divn. Supt. DATE 8/14/72

APPROVED BY W. A. Gressett TITLE OIL AND GAS INSPECTOR DATE AUG 21 1972

CONDITIONS OF APPROVAL, IF ANY: as noted