

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPLICATE*
(Other instructions on re-
verse side)

Form approved
Budget Bureau No. 1004-0135
Expires August 31, 1985

5. LEASE DESIGNATION AND SERIAL NO.

NM-0149953

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

JEFFERS FEDERAL

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

Square Lake Grayburg S

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 27, T16S, R31E

12. COUNTY OR PARISH

EDDY

13. STATE

N M

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

RECEIVED

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

GEORGE A. CHASE

3. ADDRESS OF OPERATOR

Box 367 Carlsbad, NM 88221-0367

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

SE/4 SW/4 S27, T16S, R31E

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

We intend to plug and abandon this well as follows:

1. Will notify BLM office at (505)788-6544.
2. Set CIBP at 3500' with 35' cement on top.
3. Place 9.5 PPG mud inside 5 1/2 casing.
4. Place 100' cement plug at base of salt from (1880' - 1780')
5. Place 100' cement plug at top of salt from (865' to 765') tag plug
6. Set 50' surface plug.
7. Set dry hole marker. Clean location and get it ready for inspection.

18. I hereby certify that the foregoing is true and correct

SIGNED

George A. Chase

TITLE

operator

DATE 1/4/90

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

1-17-90

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side