

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

# NEW MEXICO OIL CONSERVATION COMMISSION

RECEIVED

SEP 14 1978

O. C. C.  
ARTESIA, OFFICE

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No. 11273
7. Unit Agreement Name
8. Farm or Lease Name Bogle
9. Well No. 1
10. Field and Pool, or Wildcat Mesa Queen
12. County Eddy

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER-
2. Name of Operator Remuda Oil & Gas Company
3. Address of Operator 150 Mid America Bldg., Midland, Texas 79701
4. Location of Well UNIT LETTER J, 1980 FEET FROM THE East LINE AND 1980 FEET FROM THE South LINE, SECTION 12 TOWNSHIP 164S RANGE 31E NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 4345-GL

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Pull 4-1/2" casing cemented w/100 sax of cement @ a total depth of 3400' from as deep as possible. Spot 20 sack plug above perforations @3314-20, place 35 sax of cement at stub of 4-1/2" casing., 65 sax @ 50' above & 50' below bottom of 8-5/8" set @397'.  
10 sax in top of hole.  
Fill hole w/mud laden 9-1/2# fluid.  
Install dry hole marker.  
Plugging to be done in four to six months if possible.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Cec Barnett TITLE Agent DATE 9-12-78

APPROVED BY W. A. Gressitt TITLE SUPERVISOR, DISTRICT II DATE SEP 27 1978

CONDITIONS OF APPROVAL, IF ANY: 25 sack Plug @ TD  
100' Plug @ 2170-2270  
100' " @ 1200-1300

Notify N.M.O.C.C. in sufficient time to witness

Plugging