

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE
(Other instructions on reverse side)

Form approved.
Budget Bureau No. 42-R1424.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☐ GAS WELL ☒ OTHER ☐ Drilling Well		5. LEASE DESIGNATION AND SERIAL NO. NM-01146
2. NAME OF OPERATOR Leonard Oil Company		6. IF IN PROGRESS, LOTTERY OR OTHER NAME
3. ADDRESS OF OPERATOR Box 400 - Roswell, New Mexico		7. UNIT AGREEMENT NAME
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 660 FNL & 660 FNL of Sec.		8. FARM OR LEASE NAME Federal Humble
14. PERMIT NO.		9. WELL NO. 1
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 3725 GR, 3737 KDB		10. FIELD NO. Will
		11. AND/OR WELL NO. Sec. 1, T. 1N, R. 1E, S. 10N, E. 1E, N.M.P.M.
		12. COUNTY AND PARISH Edo

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT	
TEST WATER SHUT-OFF ☐	PULL OR ALTER CASING ☐	WATER SHUT-OFF ☐	
FRACTURE TREAT ☐	MULTIPLE COMPLETE ☐	FRACTURE TREATMENT ☐	
SHOOT OR ACIDIZE ☐	ABANDON* ☒	SHOOTING OR ACIDIZING ☐	
REPAIR WELL ☐	CHANGE PLANS ☐	(Other) ☐	

(NOTE: Report results of multiple completion or recompletion operations only when Completion or Recompletion Report and Log Form is used.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths to bottom of well.) *

In accordance with our telephone conversation of Oct. 8, 1964, we propose to plug and abandon as follows:

- Spot 30 ex cement plugs at the following intervals:
10,300 - 10,700
8,900 - 8,800
7,500 - 7,400
6,300 - 6,200
4,200 - 4,000
2,375 - 2,775
- Mud-laden fluid will be left in the interval between cement plugs.
- Pull as much 3-5/8" casing as possible. The cement top outside is at 1,700'.
- Spot 30 ex cement plug in base of 13-3/8" casing which is at 1,700'.
- Place 10 ex cement plug in top of 13-3/8" casing and erect marker.
- Level location as near as possible to its original contour.

18. I hereby certify that the foregoing is true and correct

SIGNED [Signature] TITLE General Manager.

(This space for Federal or State office use)

APPROVED BY [Signature] TITLE General Manager.

CONDITIONS OF APPROVAL, IF ANY:

APPROVED
OCT 13 1964
R. L. BULLMAN
ACTING DISTRICT ENGINEER

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.

