STATE OF NEW MEXICO				ı	
ENERGY AND MINERALS DEPARTMENT				Form C-103	
NO. OF COPIES RECEIVED	OIL CONSERVATION	N DIVIS REC EIVED		Revised 10-1-78	
DISTRIBUTION	P.0. Box 3	2088			
SANTA FE	SANTA FE. NEW M	APR 1 5 1983	5a. Indicate To	ype of Lease	
FILE	,	APR 15 1983	State X	Fee	
U.S.G.S					
LAND OFFICE		O. C. D.	5. State Oil &	Gas Lease No.	
OPERATOR		ARTESIA, OFFICE			
			E-8	560	
SUNDRY NOTICES AND REPORTS ON WELLS			XXXXXXXXXXXXXX	xxxxxxxxxxx x	
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT			L XXXXXXXXXXXXXX	xxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxx	
RESERVOIR. USE MAPPLIC	ATION FOR PERMIT-" (FORM C	-1011 FOR SUCH PROPOSALS.)	XXXXXXXXXXXXX	xxxxxxxxxxxxxx	
I. OIL GAS			7. Unit Agreem	ent Name	
WELL X	OTHER		-		
			8. Farm or Lea	8. Farm or Lease Name	
2. Name of Operator			Bogle Farms	Bogle Farms Cour.	
Read & Stevens, Inc.	The state of the s		9. Well No.		
5. Address of Operator P.O. Box 1518, Roswell, NM 88201				2	
			10. Fleid and	10. Fleid and Pool, or Wildcat	
4. Location of Well			Masa Ousan		
UNIT LETTER E . 1980	FEET FROM THE North	-	Mesa Queen		
THE West LINE, SECTION	13 TOWNSHIP 16S	RANGE 31E NMP	M \$\$\$\$\$\$\$\$\$\$\$	XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX	
×××××××××××××××××××××××××××××××××××××××	5. Elevation(Show whether	- DF,RT,GR,etc.)	12. County	XXXXXXXXXXXXXXXXX	
xxxxxxxxxxxxxxxxxxxxxxxxxxxxxx	44041 KB		Eddy	XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX	
Check Appr	opriate Box To Indicate Na	ature of Notice, Report or O	ther Data	,	
NOTICE OF INTENT		SUBSEQUENT			
					
PERFORM REMEDIAL WORK	PLUG AND ABANDON X	REMEDIAL WORK		IG CASING	
TEMPORARILY ABANDON	CHANGE PLANS	COMMENCE DRILLING OPNS.	PLUG AN	ID ABANDONMENT	
PULL OR ALTER CASING		CASING TEST AND CEMENT JO	В		
OTHER		OTHER			
Describe Proposed or Completed C	Operations(Clearly state a	II pertinent details, and qi	ve pertinent date	es, including esti-	
mated date of starting any propo	sed work) SEE RHF 1103.				
mared date of Starting any prope	GOG ROLKY SEE NOTE TOSE				
∤ 1) Pump 35sx	cmt down 2 7/8" tbg w/rub	ber plag & displace to 2350!	•		

<i>★</i> 1)	Pump SSSX CMT down 2 7/8" Tog W/Td Sbet prag & draphdes to 2550 .
2)	Cut asg @ 2325', pull asg.
3)	Spot 100' plug, 35sx, 2225'-2325', tag plug @ 2225'.
4)	Spot 100' plug, 35sx, 1275'-1375', tag plug @ 1275'.
5)	Spot 100' plug, 50sx, 300'-400', tag plug @ 300'.
6)	Set 15sx plug @ surface w/dry hole marker.
7)	Crean up location & prepare for inspection.
	ry certify that the information above is true and complete to the best of my knowledge and belief. TITLE Drilling & Production Manager DATE 4-14-83
SIGN	IFO // / AIDFIFUR THE DESIGNATION Manages DATE 4 1. 03

Original Signed By

TITLE Lessie A. Clements
Supervisor District II

DATE APR 1 8 1983

* Notify cop 24 hrs prier to setting Bim. Dlug mud between all plugs

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY: