

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE
(Other instructions on reverse side)

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

New Mex. 2064

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different use. Use "APPLICATION FOR PERMIT" for such proposals.)

RECEIVED

1. OIL WELL ☐ GAS WELL ☒ OTHER ☐	DEC 2 1974	7. UNIT AGREEMENT NAME
2. NAME OF OPERATOR Roy E. Kimsey		8. FARM OR LEASE NAME Richardson Oil-Pederal
3. ADDRESS OF OPERATOR 522 Bldg. of The Southwest Midland, Tx. 79701	O. G. C. ARTESIA. OFFICE	9. WELL NO. 1
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.) At surface 330 EL 2337 NL Sec. 4		10. FIELD AND POOL, OR WILDCAT East Henshaw Grayburg
14. PERMIT NO.	15. ELEVATIONS (Show whether DF, RT, GR, etc.) 38450R	11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA 4-16S-30E
		12. COUNTY OR PARISH Elroy
		13. STATE NM

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
TEST WATER SHUT-OFF ☐	PULL OR ALTER CASING ☐	WATER SHUT-OFF ☐	REPAIRING WELL ☐
FRACTURE TREAT ☐	MULTIPLE COMPLETE ☐	FRACTURE TREATMENT ☐	ALTERING CASING ☐
SHOOT OR ACIDIZE ☐	ABANDON* Plug ☒	SHOOTING OR ACIDIZING ☐	ABANDONMENT* ☐
REPAIR WELL ☐	CHANGE PLANS ☐	(Other) ☐	
(Other) ☐		(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)	

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Well has not been produced since Aug. 1973

Proposal: Plug & Abandon in Nov. 1974

1. Pull Rods & Tubing
2. Set CIB 2700'
3. Run tubing & displace the hole with mud laden fluid.
4. Pump 100' plug on top of CIB 2700'
5. Shoot Casing off at freepoint (approx. 1500')
6. Lay down casing & run tubing 50' inside of 4" stub.
7. Pump 100' plug 4" stub (50' in & 50' out).
8. Pull tubing to 1146' & pump 100' plug.
9. Pull tubing to 496' & pump 100' plug.
10. 20' Cement plug in top & install dryhole marker.
11. Clean location & do any dirt work required.

18. I hereby certify that the foregoing is true and correct

SIGNED

Carolyn L. Phipps

TITLE

Agent

DATE

11-18-74

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

APPROVED SUBJECT TO POSSIBLE ADDITIONAL REQUIREMENT THAT PAD AND/OR ROAD BE RIPPED AND SEEDED

DATE

*See Instructions on Reverse Side
CONTACT THIS OFFICE REGARDING ABOVE BEFORE MAKING FINAL CLEANUP.

RECEIVED
NOV 25 1974
U. S. GEOLOGICAL SURVEY
ARTESIA, NEW MEXICO

APPROVED
NOV 25 1974
J. E. BECKWITH
ACTING DISTRICT ENGINEER

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.