

1. OF COPIES RECEIVED

DISTRIBUTION

SANTA FE

FILE

U.S.G.S.

LAND OFFICE

OPERATOR

NEW MEXICO OIL CONSERVATION COMMISSION

RECEIVED

DEC 20 1975

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease

State ☐

Fee ☒

5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- Wildcat		7. Unit Agreement Name
2. Name of Operator Read & Stevens, Inc.		8. Farm or Lease Name Yates
3. Address of Operator P. O. Box 2126, Roswell, New Mexico 88201		9. Well No. 1
4. Location of Well UNIT LETTER A 660 North 660 FEET FROM THE LINE AND FEET FROM East 11 South 26 East NMPM. THE LINE, SECTION TOWNSHIP RANGE		10. Field and Pool, or Wildcat Wildcat
15. Elevation (Show whether DF, RT, GR, etc.) 3379' GR - 3393' RKB		12. County Eddy

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JCB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1703.

TD 8045', PBTD 2133'. Received verbal permission from Mr. W. A. Gressett, Artesia, New Mexico, on 10-28-75, to plug & abandon as follows:

1. Set 20 sx. cement plug across perms. 1963'-2040'.
2. Cut 4 1/2" casing @ approximately 1400' & pull casing.
3. Set 35 sx. cement plug 1450'-1300'.
4. Set 10 sx. cement plug 10' - surface.
5. Install regulation marker.
6. Cut off anchors and clean location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE Agent DATE 12-23-75

APPROVED BY [Signature] TITLE SUPERVISOR, DISTRICT II DATE DEC 29 1975

CONDITIONS OF APPROVAL, IF ANY: