

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)

1. oil ☒ well ☐ gas ☐ well ☐ other ☐

2. NAME OF OPERATOR
Eagle Oil ^{Gas} Company

3. ADDRESS OF OPERATOR
510 Hamilton Bldg., Wichita Falls, Tx. 76301

4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.) Unit I
AT SURFACE: 2,310' FSL & 660' FEL
AT TOP PROD. INTERVAL: Same.
AT TOTAL DEPTH: Same.

16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

5. LEASE	NM 8940	
6. IF INDIAN, ALLOTTEE OR TRIBE NAME		
7. UNIT AGREEMENT NAME		
8. FARM OR LEASE NAME	Crow Flats "A" Federal	
9. WELL NO.	2	
10. FIELD OR WILDCAT NAME	Wildcat	
11. SEC., T., R., M. OR BLK. AND SURVEY OR AREA	Sec. 19, T-16-S, R-28-E	
12. COUNTY OR PARISH	13. STATE	
Eddy	New Mexico	
14. API NO.		
15. ELEVATIONS (SHOW DE KDB, AND WD)	3,604' DE	

REQUEST FOR APPROVAL TO:

SUBSEQUENT REPORT OF:

- | | |
|----------------------|-------------------------------------|
| TEST WATER SHUT-OFF | ☐ |
| FRACTURE TREAT | ☐ |
| SHOOT OR ACIDIZE | ☐ |
| REPAIR WELL | ☐ |
| PULL OR ALTER CASING | ☐ |
| MULTIPLE COMPLETE | ☐ |
| CHANGE ZONES | ☐ |
| ABANDON* | ☒ |
| (other) | ☐ |

--	--	--	--	--	--	--	--

RECEIVED
FEB 19 1982
(NOTE: Rep
cha)

(NOTE: Report results of multiple completion or zone change on Form 9-330.)

OIL & GAS
U.S. GEOLOGICAL SURVEY
ROSWELL, NEW MEXICO

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

- 1) Set Cast Iron Bridge Plug @1,700' and dump 35' of cement on plug.
- 2) Run tubing and load hole with 9.5 PPG mud.
- 3) Run free point and cut-off 4-1/2" casing @free-point
- 4) Spot 25 sack cement plug @cut-off point thru 4-1/2" casing.
- 5) Spot 35 sack plug @454' back to 354' in 7-7/8" open hole & 8-5/8" casing.
- 6) Spot 15 sack plug from 30' to surface in 8-5/8" casing.
- 7) Set marker, remove head, and fill mouse-hole & rat-hole.

Subsurface Safety Valve: Manu. and Type

- 18. I hereby certify that the foregoing is true and correct**

SIGNED

Don E. Bennett

TITLE Agent

DATE _____

(This space for Federal or State office use)

APPROVED BY
CONDITIONS OF

APPROVED

TITLE

DATE _____

APPROVAL IF ANY:

FEB 22 1982

JAMES A. GILLHAM
DISTRICT SUPERVISOR

***See Instructions on Reverse Side**