

Form 3160-5
(November 1983)
(Formerly 9-4331)

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPI
(Other instructions
verse side)

TE
re

Form approved
Budget Bureau No. 1004-0135
Expires August 31, 1985

c/sf

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT" for such proposals.)

DEC 26 1984

O. C. D.

ARTESIA OFFICE

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR
CASA PETROLEUM, INC.

3. ADDRESS OF OPERATOR
105 North 6th, Artesia, New Mexico 88210

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.
See also space 17 below.)
At surface

1650' FSL & 330' FWL of Section

(NW $\frac{1}{4}$ SW $\frac{1}{4}$)
(Unit L)

14. PERMIT NO.

--

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3756'

5. LEASE DESIGNATION AND SERIAL NO.

NM-7724

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

--

7. UNIT AGREEMENT NAME

--

8. FARM OR LEASE NAME

HIGHWEST FEDERAL

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

W/C Grbg - SA
Undesignated

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 7-16S-30E

12. COUNTY OR PARISH

Eddy

13. STATE

NM

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

PULL OR ALTER CASING

FRACTURE TREAT

MULTIPLE COMPLETION

SHOOT OR ACIDIZE

ABANDON*

REPAIR WELL

CHANGE PLANS

(Other)

X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

TD 3435' (PB 2875'). Salt section 460 - 950'.
8 5/8" - 454' - Circ. 4 1/2" - 2883' - 500 sx (TC-1250').
Perforations 2449 - 2764'.

Plan to plug well as follows:

Set 35 sx cement in 4 1/2" csg from 2800 - 2300'.
Fill hole with mud.
Shoot off 4 1/2" csg at top of cement.
Isolate salt section by spotting:
25 sx cement at top of 4 1/2" stub. - tag
50 sx cement across shoe of 8 5/8" csg.
Tag plug in 8 5/8" csg.
Set 20 sx cement at surface.
Set Dry Hole Marker.

This plan is in accordance with telephone conversation between Mr. Patch Karr
of Casa Petroleum and Mr. Bob Pitschke of the BLM on May 29, 1984.

18. I hereby certify that the foregoing is true and correct

SIGNED

James A. Knaut

TITLE

Agent

DATE

July 5, 1984

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

12-21-84

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side