

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE*
(Other instructions on re-
verse side)

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

NM-30067

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Sara Fed.

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

Wildcat - San Andres

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA

Sec. 10-T16S-R28E

12. COUNTY OR PARISH

Eddy

13. STATE

NM

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL GAS WELL OTHER Dry Hole

2. NAME OF OPERATOR
McClellan Oil Corporation

3. ADDRESS OF OPERATOR
P.O. Drawer 730, Roswell, NM 88202

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.
See also space 17 below.)
At surface
1980' FSL & 1980' FEL

RECEIVED BY
DEC 12 1985
O. C. D.
ARTESIA, OFFICE

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, AT, GR, etc.)

3601' G.L.

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

TEST WATER SHUT-OFF
FRACTURE TREAT
SHOOT OR ACIDIZE
REPAIR WELL
(Other)

PULL OR ALTER CASING
MULTIPLE COMPLETE
ABANDON* XX
CHANGE PLANS

WATER SHUT-OFF
FRACTURE TREATMENT
SHOOTING OR ACIDIZING
(Other)

REPAIRING WELL
ALTERING CASING
ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

Propose to plug and abandon as follows:

Top of Queen - 1093'; top of San Andres - 1840'. No shows below 8-5/8" casing.

- ① Set 25 sx plug at T.D. (1845').
- Set 50 sx plug in and out of the 8-5/8" shoe at 732'. - Tag
- Set 50' plug at surface with 25 sx.
- Heavy mud placed between all plugs.
- Install dry hole marker. Clean and level location.

① 100' plug 1500'
1600'
100' plug 1000'
1100'



Post ID-2
1-24-86
P4A

18. I hereby certify that the foregoing is true and correct.

SIGNED Paul Rogstadale

TITLE Operations Manager

DATE 12/6/85

(This space for Federal or State office use)

APPROVED BY _____
CONDITIONS OF APPROVAL, IF ANY:

TITLE _____

DATE _____