

45P

Form 3-231
(May 1987)

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE*
(Other instructions on re-
verse side)

Form approved.
Budget Bureau No. 42-R1424

5. LEASE DENIGATION AND SERIAL NO.
NM-10276

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME
TXO Federal

9. WELL NO.

10. FIELD AND POOL, OR WILDCAT
High Lonesome - Queen

11. SEC., T., R., W., OR BLK. AND
SURVEY OR AREA

Sec. 8-T16S-R29E

12. COUNTY OR PARISH 13. STATE
Eddy NM

SUNDRY NOTICES AND REPORTS ON WELLS
(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. ☐ NEW WELL ☒ RE-DRILL WELL ☐ OTHER

2. NAME OF OPERATOR
McClellan Oil Corporation ✓

3. ADDRESS OF OPERATOR
P.O. Drawer 730, Roswell, NM 88202

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.
See also space 17 below.)
At surface

660' FSL & 660' FWL

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GA, etc.)

3661' G.L.

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐ PULL OR ALTER CASING ☐
FRACTURE TREAT ☐ MULTIPLE COMPLETION ☐
SHOOT OR ACIDIZE ☐ ABANDON* ☒
REPAIR WELL ☐ CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐ REPAIRING WELL ☐
FRACTURE TREATMENT ☐ ALTERING CASING ☐
SHOOTING OR ACIDIZING ☐ ABANDONMENT* ☐
(Other) _____

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any
proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones perti-
nent to this work.) *

As per Peter Chester (1-21-86):

Propose to plug and abandon by:

Set 25 sx cement plug from 1570' to 1669' inside 5-1/2" casing and tag.
Set 25 sx cement plug from 600' to 700'.
Set 25 sx cement plug from 170' to 270' across 8-5/8" shoe inside 5-1/2" casing.
Set 50 sx cement plug down bradenhead to cover 8-5/8" shoe.
Set 10 sx surface plug.

Install dry hole marker.

18. I hereby certify that the foregoing is true and correct

SIGNED Paul R. Reynolds TITLE Operations Manager

DATE 1/31/86

(This space for Federal or State office use)

APPROVED BY _____
CONDITIONS OF APPROVAL, IF ANY:

TITLE _____

DATE 2-6-86