

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT
OIL GASES IN TRIPPLICATE
(Other Instructions on Re-
verse Side)
Artesia, NM 88210

Form approved.
Budget Bureau No. 1004-0135
Expires August 31, 1985

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT" for such proposals.)

RECEIVED

JAN 20 '89

ARTESIA, OFFICE

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

McClellan Oil Corporation ✓

3. ADDRESS OF OPERATOR

P.O. Drawer 730, Roswell, N.M. 88202

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.)

See also space 17 below.)
At surface

990 FNL & 660 FWL

14. PERMIT NO.

15. ELEVATIONS (Show whether DE, RT, GR, etc.)

3635' G.L.

5. LEASE DESIGNATION AND SERIAL NO.

NM-41642

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Exxon Fed.

9. WELL NO.

2

10. FIELD AND POOL, OR WILDCAT

High Lonesome *Green*

11. SEC., T., R., M., OR B.L. AND SURVEY OR AREA

Sec. 28-T16S-R29E

12. COUNTY OR PARISH 13. STATE

Eddy

NM

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.) *

Propose to plug and abandon: 8 5/8" set at 295 ft. Cement Circulated
5 1/2" set at 2020 ft. TOC at 1050 ft.
Perfs: 1922-1925

a. Set 25 sx Cement plug from 1850' to 1950'. [TAG]

b. Shoot off casing at 1000 ft and pull.

SJS

c. Set 25 sx Cement plug from 950' to 1050'. [TAG]

d. Set 35 sx Cement plug from 245' to 345'. [TAG]

e. Set 10 sx Cement plug at surface.

Install dry hole marker, remove all equipment. Clean and level location.

18. I hereby certify that the foregoing is true and correct

SIGNED

Karl R. Rude

TITLE Operations Manager

DATE 1/4/89

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE 1-17-89

*See Instructions on Reverse Side