

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPPLICATE*
(Other instructions on re-
verse side)

Form approved.
Budget Bureau No. 1004-0135
Expires August 31, 1985

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT" for such proposals.)

1. OIL WELL ☐ GAS WELL ☒ OTHER P&A		5. LEASE DESIGNATION AND SERIAL NO. NM-0916	
2. NAME OF OPERATOR McCLELLAN OIL CORPORATION		6. IF INDIAN, ALLOTTEE OR TRIBE NAME	
3. ADDRESS OF OPERATOR P.O. Drawer 730, Roswell, N.M. 88202		7. UNIT AGREEMENT NAME	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 660' FSL & 1980' FWL		8. FARM OR LEASE NAME Golden Bear Fed	
14. PERMIT NO. 30-015-25589		9. WELL NO. 1	
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 3727KB		10. FIELD AND POOL, OR WILDCAT Wildcat/U Penn	
16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data		11. SEC., T., R., M., OR BLK. AND SURVEY OR ARMA Sec. 24-T16S-R29E	
17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)		12. COUNTY OR PARISH Eddy	
		13. STATE NM	

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

We Propose to P&A well as follows:

1. Set C.I.B.P. at 9240', W/30' Cmt on top.
2. Set C.I.B.P. at 8650', W/30' Cmt on top.
3. Cut csg off at 8500' and pull out of hole.
4. Thru Tbg - Cmt plugs
 - A. 8850'-8450' - 35 sx plug - tag
 - B. 7500'-7400' - 35
 - C. 6400'-6300' - 35 sx
 - D. 5300'-5200' - 35
 - E. 4300'-4200' - 35 sx
 - F. 3300'-3200' - 35
 - G. 2650'-2550' - 40 sx - TAG
 - H. 1650'-1550' - 35
 - I. 550' - 450' - 35 - TAG
 - J. 60' to surface 20 sx

-----All plugs will have heavy mud between plugs.

Install dry hole marker.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE Drlg. & Comp. Eng.

DATE 5-26-92

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE 6/8/92

NOTIFY BLM - - - -

*See Instructions on Reverse Side