

Submit 3 Copies To Appropriate District Office
District I
1625 N. French Dr., Hobbs, NM 88240
District II
811 South First, Artesia, NM 87210
District III
1000 Rio Brazos Rd., Aztec, NM 87410
District IV
1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico
Energy, Minerals and Natural Resources

Form C-103
Revised March 25, 1991

CISF
Bj

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

WELL API NO.
30-015-02875

5. Indicate Type of Lease
STATE ☒ FEE ☐

6. State Oil & Gas Lease No.
B11662

7. Lease Name or Unit Agreement Name:
Cave Pool Unit

8. Well No.
16

9. Pool name or Wildcat
Greyburg, Jackson, SA, QN

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:
Oil Well ☒ Gas Well ☐ Other ☐

2. Name of Operator
Marks and Garner Production Co. Ltd. ✓

3. Address of Operator
P.O. Box 70 Lovington NM 88260

4. Well Location

Unit Letter E : 1973.4 feet from the North line and 330 feet from the West line
Section 03 Township 17S Range 29E NMPM County Eddy

10. Elevation (Show whether DR, RKB, RT, GR, etc.)

11. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

| NOTICE OF INTENTION TO: | | SUBSEQUENT REPORT OF: | |
|--|--|---|---|
| PERFORM REMEDIAL WORK <input type="checkbox"/> | PLUG AND ABANDON <input checked="" type="checkbox"/> | REMEDIAL WORK <input type="checkbox"/> | ALTERING CASING <input type="checkbox"/> |
| TEMPORARILY ABANDON <input type="checkbox"/> | CHANGE PLANS <input type="checkbox"/> | COMMENCE DRILLING OPNS. <input type="checkbox"/> | PLUG AND ABANDONMENT <input type="checkbox"/> |
| PULL OR ALTER CASING <input type="checkbox"/> | MULTIPLE COMPLETION <input type="checkbox"/> | CASING TEST AND CEMENT JOB <input type="checkbox"/> | |
| OTHER: <input type="checkbox"/> | | OTHER: <input type="checkbox"/> | |

12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompilation.

Go in hole with 2" tubing with CIBP. Set CIBP @ 2372'. Spot 10 sxs cement plug on top of CIBP. Circulate hole with 10# brine and 25 sxs of salt gel. Come out of hole with tubing. Wait 24hr. Go in hole with tubing and tag cement plug. Come out of hole with tubing. Shoot 4½" casing @ 1800'. Come out of hole with casing. Go in hole with tubing and spot 50' cement plug in and out. come out of hole. Wait 24 hr. Go in hole and tag cement plug. Come up hole to 915' and spot 100' cement plug. Come out of hole. Wait 24hr. Go in and tag cement plug. come up and spot 100' cement plug 390' @ 315' Tag. Come out of hole. spot 20 sxs plug @ surface and set dry hole marker. Port 8 5/8 csg. Squeeze 60' of amt inside & outside csg.

Notify OCD 24 hrs. prior to any work done

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE _____ TITLE Agent RECEIVED OCD - ARTESIA DATE 12-17-01

Type or print name Devin Garner Telephone No. (505) 396-5326
(This space for State use)

APPROVED BY _____ TITLE _____ DATE 1-2-02
Conditions of approval, if any