

Submit 3 Copies To Appropriate District Office
District I
1625 N. French Dr., Hobbs, NM 88240
District II
811 South First, Artesia, NM 87210
District III
1000 Rio Brazos Rd., Aztec, NM 87410
District IV
1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico
Energy, Minerals and Natural Resources

Form C-10
Revised March 25, 199

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

WELL API NO.
30-015-02881

5. Indicate Type of Lease
STATE ☒ FEE ☐

6. State Oil & Gas Lease No.
B11662

7. Lease Name or Unit Agreement Name:
Cave Pool Unit

8. Well No.
14

9. Pool name or Wildcat
Greyburg, Jackson, SA, QN

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:

Oil Well ☒ Gas Well ☐ Other

2. Name of Operator

Marks and Garner Production Co. Ltd.

3. Address of Operator

P.O. Box 70 Lovington NM 88260

4. Well Location

Unit Letter G : 1980 feet from the North line and 1980 feet from the East line

Section 04

Township 17S

Range 29E

NMPM

County Eddy

10. Elevation (Show whether DR, RKB, RT, GR, etc.)

11. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒

TEMPORARILY ABANDON ☐ CHANGE PLANS ☐

PULL OR ALTER CASING ☐ MULTIPLE COMPLETION ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐

CASING TEST AND CEMENT JOB ☐

OTHER: ☐

12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompilation.

Go in hole with 2" tubing with CIBP. Set CIBP @ 2316'. Spot 10 sxs cement plug on top of CIBP. Circulate hole with 10# brine and 25 sxs of salt gel. come out of hole and wait 24hr. Go in hole and tag cement plug. Come out of hole and shoot 4 1/2" casing off @ 1950'. Come out of hole with casing. go in and spot 50' cement plug in and out. come out and wait 24hr. go in and tag. come up to 862 - 862 and spot 100' cement plug. come out and wait 24hr. Go in and tag plug come up and spot 100' plug @ 470'. Come out of hole and spot 20 sxs plug @ surface and set dry hole marker.

Notify OCD 24 hrs. prior to any work done

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE _____ TITLE Agent DATE 12-17-01

Type or print name Devin Garner

(This space for State use)

APPROVED BY _____ TITLE _____ DATE 1-2-02

Conditions of approval, if any