

Form 3160-5  
(June 1990)

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

Arapaho Oil and Gas

3. Address and Telephone No.

P.O. Box 1517 Roswell New Mexico 88201

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

Sec 5, T-17S, R-29E  
990 FNL & 1980 FEL

NM OIL CONS COMMISSION  
Drawer DD  
Artesia, NM 88210

RECEIVED

AUG 24 '94

O. C. D.  
ARTESIA OFFICE

FORM APPROVED

Budget Bureau No. 1004-0135  
Expires: March 31, 1993

5. Lease Designation and Serial No.

710153 NM 011331

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation  
Cave Pool Unit

8. Well Name and No.

CPU #8

9. API Well No.

10. Field and Pool, or Exploratory Area

11. County or Parish, State

Eddy County, N.M.

12. CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent  
☐ Subsequent Report  
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment  
☐ Recompletion  
☐ Plugging Back  
☐ Casing Repair  
☐ Altering Casing  
☐ Other

- ☐ Change of Plans  
☐ New Construction  
☐ Non-Routine Fracturing  
☐ Water Shut-Off  
☐ Conversion to Injection  
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

1. Set plug (CIBP) at 2500' and cap W/ 35' cmt
2. Set CIBP at 2100' and cap W/ 35' cmt
3. Free point tbg and cut off 50' above free point
4. set 50 sx plug at top of tbg
5. Set 50 sx plug at 365' 50' below csg shoe
6. Tag plug at shoe
7. Set 10 sx plug at surface and cut off well head erect 4" marker 4' above ground level W/ following information welded on marker.

Arapaho Oil and Gas  
CPU #8  
Sec 5, T-17S, R-29E  
1980 FEL & 990' FNL  
Eddy Co, N.M.

8. Cut off anchors below ground level, clean location and reseed per BLM requirements.

14. I hereby certify that the foregoing is true and correct

Signed

*[Signature]*

Title Consultant

Date August 1, 1994

(This space for Federal or State office use)

(ORIG. SCD) JOE G. LARA

Approved by

Conditions of approval, if any:

Sec attached. Also tag plug @ tbg studs.

Title

PETROLEUM ENGINEER

Date

8/23/94

RECEIVED  
AUG 1 12 36 PM '94  
CART  
ARTESIA

RECEIVED