

Submit 3 Copies To Appropriate District Office

District I

1625 N. French Dr., Hobbs, NM 88240

District II

811 South First, Artesia, NM 87210

District III

1000 Rio Brazos Rd., Aztec, NM 87410

District IV

1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico  
Energy, Minerals and Natural Resources

OIL CONSERVATION DIVISION  
1220 South St. Francis Dr.  
Santa Fe, NM 87505

Form C-103

Revised March 25, 1997

WELL API NO.

30-015-02927

5. Indicate Type of Lease

STATE ☒ FEE ☐

6. State Oil & Gas Lease No.

NM397624

7. Lease Name or Unit Agreement Name:

Cave Pool Unit

8. Well No.

32

9. Pool name or Wildcat

Greyburg, jackson, SA, QN

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:

Oil Well ☒ Gas Well ☐ Other ☐

2. Name of Operator

Marks and Garner Production Co. Ltd.

3. Address of Operator

P.O. BOX 70 Lovington NM 88260

4. Well Location

Unit Letter A : 660 feet from the North line and 660 feet from the East line

Section 09

Township 17S Range 29E

NMPM

County Eddy

10. Elevation (Show whether DR, RKB, RT, GR, etc.)

11. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒

TEMPORARILY ABANDON ☐ CHANGE PLANS ☐

PULL OR ALTER CASING ☐ MULTIPLE COMPLETION ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐

CASING TEST AND CEMENT JOB ☐

OTHER: ☐

12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompilation.

Go in hole with 2" tubing with CIBP. Set CIBP @ 2368'. Spot 10 sxs cement plug on top of CIBP. Circulate hole with 10# brine and 25 sxs of salt gel. Come out and wait 24hr. go in hole and tag plug. come out and shoot 4 1/2" casing @ 1900'. Come out with casing and go in with tubing and spot 50' cement plug in and out. Come out and wait 24hr. Go in hole and tag plug. Come up to 825', and spot 100' cement plug. come out of hole and wait 24hr. Go in hole and tag plug. Come up hole and spot cement ~~100'~~ cement plug @ 482' ~~74'~~ Come up hole and spot 20 sxs cement plug @ surface. Set dry hole marker.

Notify OCD 24 hrs. prior to any work done

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE

TITLE Agent

RECEIVED  
OCD - ARTESIA

DATE 12-17-01

Type or print name Devin Garner

Telephone No. (505) 396-5326

(This space for State use)

APPROVED BY

TITLE

DATE

Conditions of approval, if any: