

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

N.M. Oil Cons. Division  
811 S. 1st Street  
Artesia, NM 88210-2894

FORM APPROVED  
Budget Bureau No. 1004-0135  
Expires: March 31, 1993  
Serial No. and Serial No.  
LC-028793A

**SUNDRY NOTICES AND REPORTS ON WELLS**

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.  
Use "APPLICATION FOR PERMIT-" for such proposals

**SUBMIT IN TRIPLICATE**

1. Type of Well

☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

Marbob Energy Corporation

3. Address and Telephone No.

P.O. Drawer 227, Artesia, NM 88210

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

2310 FSL, 330 FEL, Sec.19, T17S, R30E, Unit I

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

Burch Keely Unit #99

9. API Well No.

30-015-04203

10. Field and Pool, or Exploratory Area

Grbg Jackson Sr Q Grbg Sa

11. County or Parish, State

Eddy County, NM

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent  
☐ Subsequent Report  
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment  
☐ Recompletion  
☐ Plugging Back  
☐ Casing Repair  
☐ Altering Casing  
☐ Other \_\_\_\_\_  
☐ Change of Plans  
☐ New Construction  
☐ Non-Routine Fracturing  
☐ Water Shut-Off  
☐ Conversion to Injection  
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

Notify BLM 24 hrs. before starting

1. POH w/ rods & tubing \*  
2. RIH spot 100' plug @ 2520 (perf 2532 to 2712) woc 925  
3. Perf. 7" casing @ 840' sqz 100' plug (base salt 788") woc TAG  
4. Perf 7" casing @ 540' sqz 225' cmt (8 1/4 shoe 490, top salt 385") TAG  
5. Perf 7" casing @ 60' circulate cmt to surface  
6. cut off well head install dry hole marker

\*\*\*Set CIBP within 50 to 100 feet above the open perforations and cap with 35 feet of cement;  
or

\*\*\*Set a cement plug which extends to a minimum of 50 feet below to 50 feet above the perforated interval. TAG

**SEE ATTACHED FOR  
CONDITIONS OF APPROVAL**

14. I hereby certify that the foregoing is true and correct

Signed Wynne Brooks

Title Agent

Date 3-27-01

(This space for Federal or State office use)

Approved by (ORIG. SGD.) ALEXIS C. SWOBODA

Title PETROLEUM ENGINEER

Date APR 03 2001

Conditions of approval, if any: