

UNITED STATES DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

Form approved.
Budget Bureau No. 42-K1424.

5. LEASE DENIGATION AND SERIAL NO.

LC 028936 (G)

6. IF INDIAN, ALIOTTAGE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a deeper oil.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☐ GAS WELL ☐ OTHER ☐ WIW - TA SEP 2 1982

2. NAME OF OPERATOR NEWMONT OIL COMPANY O. C. D.

3. ADDRESS OF OPERATOR P. O. BOX 1305 ARTESIA, NEW MEXICO 88210

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

330' FSL 990' FEL Sec. 31-17S-30E

14. PERMIT NO. 15. ELEVATIONS (Show whether DF, RT, GR, etc.)
3553'

7. UNIT AGREEMENT NAME LOCO HILLS FLOOD

8. FARM OR LEASE NAME Brigham

9. WELL NO. 1

10. FIELD AND POOL, OR WILDCAT LOCO HILLS (O. G. SA)

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA

Sec. 31-17S-30E

12. COUNTY OR PARISH 13. STATE
EDDY NEW MEXICO

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

- Spot sufficient cement across producing interval to tie back to production string casing seat, or set bridge plug near casing seat and cap with 25 sack cement plug.
- Perforate base of salt @ 1175' and squeeze with 50 sacks cement leaving 100' plug in casing.
- Perforate top of salt @ 440' and squeeze with 50 sacks cement leaving 100' plug in casing.
- Set 15 sack cement plug @ surface tying surface and production casing together.
- Erect permanent well marker

Note: (a). Your office will be notified 24 hrs. prior to operations
(b.) All plugs will be verified
(c.) Hole will be loaded between all plugs with 10# Mud
(d) We do not plan to pull any casing

RECEIVED
JUL 30 1982

U.S. GEOLOGICAL SURVEY
ROSWELL, NEW MEXICO

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE

Area Manager

DATE

7/28/82

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF

(Orig. 534) PETER W. CHESTER

AUG 31 1982

FOR

JAMES A. GILLHAM
DISTRICT SUPERVISOR

*See Instructions on Reverse Side