

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)

1. oil ☐ well gas ☐ well other ☒ Water Injection

2. NAME OF OPERATOR

General American Oil Company of Texas ✓

3. ADDRESS OF OPERATOR

P.O. Box 128 Loco Hills, New Mexico 88255

4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)

AT SURFACE:

AT TOP PROD. INTERVAL: 2310' FSL and 2232' FWL

AT TOTAL DEPTH:

16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO:

TEST WATER SHUT-OFF ☐
FRACTURE TREAT ☐
SHOOT OR ACIDIZE ☐
REPAIR WELL ☐
PULL OR ALTER CASING ☐
MULTIPLE COMPLETE ☐
CHANGE ZONES ☐
ABANDON* ☒
(other) _____

SUBSEQUENT REPORT OF:

RECEIVED

OCT 14 1982

O. C. D.
ARTESIA, OFFICE

(NOTE: Report results of multiple completion or zone change on Form 9-330.)

RECEIVED
OCT 21 1982

OIL & GAS
U.S. GEOLOGICAL SURVEY
ROSWELL, NEW MEXICO

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

DATA: NO SURFACE CASING

7" 23# casing @ 2800' with 394 sacks.

1. Dig small workover pit.
2. Pull Tubing
3. Spot 100' Plug from 2825' - 2725' to cover open hole section. (25' outside and 75' inside of 7").
4. Perforate 4 holes @ top of Yates (1260'), and squeeze 55 sacks of cement into formation. (Continued on Back).

Leave 100' cmt. plug in casing. (A.W.C.)

Subsurface Safety Valve: Manu. and Type _____ Set @ _____ Ft.

18. I hereby certify that the foregoing is true and correct

SIGNED

Lendell N. Hawkins
Lendell N. Hawkins

TITLE Field Supt.

DATE September 21, 1982

APPROVED

APPROVE (Orig. Sgd.) PETER W. CHESTER
CONDITIONS OF APPROVAL, IF ANY:

OCT 13 1982

FOR

JAMES A. GILLHAM
DISTRICT SUPERVISOR

*See Instructions on Reverse Side

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.

5. Perforate 4 holes @ top of salt (495') and squeeze 55 sacks of cement into formation.
Leave 100' cement plug in casing (P.W.C.)
6. Perforate 4 holes @ water zone (390' - 400'), and squeeze 55 sacks of cement into formation.
7. Set 10 sack surface Plug. *(at least 50') (P.W.C.)*
8. Erect permanent well marker.
9. Clean, Level, and Rip location and roads.
10. Re-seed Location and Road to Federal Specifications.