

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRI
(Other Instruction on re-
verse side)

Form approved.
Budget Bureau No. 1001-0135
Expires August 31, 1985

5. LEASE DESIGNATION AND SERIAL NO

LC-029435-A

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT-" for such proposals.)

1. ☐ OIL WELL ☐ GAS WELL ☐ OTHER ☒ WIW

2. NAME OF OPERATOR
Hondo Oil & Gas Company

3. ADDRESS OF OPERATOR
P. O. Box 2208, Roswell, NM 88202

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface
330' FSL & 2310' FEL

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, ARTESIA, OFFICE)
3697' GR

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

J. L. Keel "A"

9. WELL NO.

5

10. FIELD AND POOL, OR WILDCAT

Grayburg Jackson

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 7-T17S-R31E

12. COUNTY OR PARISH 13. STATE

Eddy

NM

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

PULL OR ALTER CASING

FRACTURE TREAT

MULTIPLE COMPLETE

SHOOT OR ACIDIZE

ABANDON*

REPAIR WELL

CHANGE PLANS

(Other) Plug & Abandon

X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

REPAIRING WELL

FRACTURE TREATMENT

ALTERING CASING

SHOOTING OR ACIDIZING

ABANDONMENT*

(Other)

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

We plan to plug this well as follows:

- (1) RIH to 3150' with 1 1/4" tubing. Spot 60 sx. cement plug.
- (2) Pull up to 1006' and reverse out excess cement.
- (3) POH with tubing.
- (4) WOC 4 hrs.
- (5) Pump 250 sx. Class "C" cement w/10% CalSeal.
- (6) Cut off casing head.
- (7) Install dry hole marker.
- (8) Clean up location.

18. I hereby certify that the foregoing is true and correct

SIGNED

Ken Brown

TITLE Engineer

DATE 3/9/89

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

3-20-89

*See Instructions on Reverse Side