Form 3160-5 (June 1990)

LED STATES DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT

N.M. O Cons. Division APPROVED

811 S. 1st Street Budget Bureau No. 1004-0135 Expires: March 31, 1993

Artesia, N.M. 38240 2864 n and Serial No.

		NM 1404U
SUNDRY NOTICES AND REPORTS ON WELLS Do not use this form for proposals to drill or to deepen or reentry to a different reservoir. Use "APPLICATION FOR PERMIT-" for such proposals		6. If Indian, Allottee or Tribe Name
SUBMIT IN TRI	IPLICATE	7. If Unit or CA, Agreement Designation
ype of Well		
Oil Gas Well Other Injection		8. Well Name and No.
ame of Operator		Blue Streak Federal #1
lack Energy Corporation		9. API Well No.
ddress and Telephone No.		30-015-21308
.O. Box 960, Artesia, NM 88211-0960 ocation of Well (Footage, Sec., T., R., M., or Survey Description)		10. Field and Pool, or Exploratory Area Eddy Undes Abo (Gas)
Sec 29, T17S, R29E, 1980 FSI & 660' FEL UT. I		11. County or Parish, State
		Eddy NM
CHECK APPROPRIATE BOX(s) TO IN	IDICATE NATURE OF NOTICE, REPORT, C	OR OTHER DATA
TYPE OF SUBMISSION	TYPE OF ACTION	
Notice of Intent	X Abandonment	Change of Plans
	Recompletion	New Construction
Subsequent Report	Plugging Back	Non-Routine Fracturing
Final Abandonment Notice	Casing Repair	Water Shut-Off
	Altering Casing	Conversion to Injection
Describe Proposed or Completed Operations (Clearly state all per directionally drilled, give subsurface locations and measured and	rtinet details, and give pertinent dates, including estimated date true vertical depths for all markders and zones pertinent to this	Dispose Water (Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.) of starting any proposed work. If well is work.)*
Describe Proposed or Completed Operations (Clearly state all per directionally drilled, give subsurface locations and measured and to Notify BLM 24 hrs. Before striating 1 RIH tag CIBP @ 7150 circulate well w/ 9.8# m 2. Cut & pull 5 1/2 from 4600' + or - 3. RIH spot 100' plug 50' in 50' out stub 4. Spot 100' plug 2707 (8 5/8 shoe 2657') 5. Spot 100' plug 1200' (salt) 6. Spot 100' plug 394 (11 3/4 shoe 344) 7. Circulate cmt from 30' to surface 8. Cut off well head install dry hole marker	rtinet details, and give pertinent dates, including estimated date true vertical depths for all markders and zones pertinent to this	(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.) of starting any proposed work. If well is
directionally drilled, give subsurface locations and measured and to Notify BLM 24 hrs. Before striating 1 RIH tag CIBP @ 7150 circulate well w/ 9.8# m 2. Cut & pull 5 1/2 from 4600' + or - 3. RIH spot 100' plug 50' in 50' out stub 4. Spot 100' plug 2707 (8 5/8 shoe 2657') 5. Spot 100' plug 1200' (salt) 6. Spot 100' plug 394 (11 3/4 shoe 344) 7. Circulate cmt from 30' to surface	rtinet details, and give pertinent dates, including estimated date true vertical depths for all markders and zones pertinent to this mud Title Agent	(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.) of starting any proposed work. If well is work.)*