

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

FOR SUBMIT IN TR. DATE
(Other Instructions on Reverse Side)

Form approved
Budget Bureau No. 1001-01-00
Expires August 31, 1989

clsf

NOTICE AND REPORTS ON WELLS

Application for proposals to drill or to deepen or plug back to a different depth.
Use "APPLICATION FOR PERMIT" for such proposals.

RECEIVED

SEP 13 '89

O. C. D.
OFFICE

1. TYPE OF WELL: ☒ WELL ☐ OTHER

2. NAME OF OPERATOR

Beach Exploration, Inc.

3. ADDRESS OF OPERATOR

800 N. Marienfeld Suite 200 Midland, Texas 79701

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.
See also space 17 below.)
At surface

1980' FSL & 1535' FWL

(Unit K)
(NE/4 SW/4)

14. PERMIT NO.

30-015-25752

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3678' KB, 3669' GL

5. LEASE DESIGNATION AND SERIAL NO.

NM 14847

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Phillips Federal

9. WELL NO.

2

10. FIELD AND POOL, OR WILDCAT

Grayburg Jackson, SR, QN, GB, SA

11. SEC. T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 7, T17S, R29E

12. COUNTY OR PARISH 13. STATE

Eddy

NM

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

X

SUBSEQUENT REPORT OF:

WATER SHUT OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATION. Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.*

Plug and Abandon (due to uneconomical production rates) as follows:

- 1). Spot 25 Sx. cement plug 2350' - 2000' (top perf @2384').
- 2). Tag plug at least 50' above 2350' with wireline.
- 3). Load hole with mud (25 Sx. gel per 100 bbls. water).
- 4). Spot 25 Sx. Cement plug from 300' to surface.
- 5). Remove all equipment, clean location, and install marker as required.

Estimated plugging date 9/15/89.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE Engineer

DATE

8-17-89

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

9-11-89

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side