

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. B-8156	

SUNDRY NOTICES AND REPORTS ON WELLS <small>(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)</small>	
1. CIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Cities Service Oil Company	8. Farm or Lease Name State BW
3. Address of Operator Box 69 - Hobbs, New Mexico 88240	9. Well No. 12
4. Location of Well UNIT LETTER I 2970 FEET FROM THE North LINE AND 960 FEET FROM THE East LINE, SECT ON 24 TOWNSHIP 18S RANGE 27E NMPM.	10. Field and Pool, or Wildcat Artesia (Q.G.S.A.)
15. Elevation (Show whether DF, RT, GR, etc.) Not Available	12. County Eddy

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

We propose to plug and abandon the above captioned well in the following manner:

1. Load the hole with mud laden fluid.
2. Set 30 sack cement plug @ approximately 1945-2045 FSD.
3. Set 30 sack cement plug @ approximately 450-510 (1/2 in and 1/2 out of 8 5/8" casing set and cemented @ 480.
4. Set 10 sack cement surface plug and approximately 0 - 30 with a 4' pipe marker extending 4' above surface to designate a P & A location.
5. Clean all debris and equipment from location.

RECEIVED

MAR 26 1969

O. C. C.

ARTESIA, OFFICE

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

ORIGINAL SIGNED
E. D. ROBERTSON

SIGNED _____ TITLE **District Office Manager** DATE **March 25, 1969**

APPROVED BY **W. A. Gressett** TITLE **OIL AND GAS INSPECTOR** DATE **MAR 26 1969**

CONDITIONS OF APPROVAL, IF ANY: **a 30 sack Plug @ top of Queen approx. 1350**