

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	/
FILE	/
U.S.G.S.	
LAND OFFICE	
OPERATOR	/

RECEIVED
NEW MEXICO OIL CONSERVATION COMMISSION

JAN 6 1971

O. O. O.
ARTESIA, OFFICE

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>

5. State Oil & Gas Lease No.
647

--

7. Unit Agreement Name
-

8. Farm or Lease Name
Resler Yates State

9. Well No.
25

10. Field and Pool, or Wildcat
Artesia

--

12. County
Eddy

--

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>
--

2. Name of Operator
AMERICAN PETROFINA COMPANY OF TEXAS

3. Address of Operator
Box 1311, Big Spring, Texas 79720

4. Location of Well
UNIT LETTER <u>I</u> FEET FROM THE <u>-</u> LINE AND <u>-</u> FEET FROM

THE <u>-</u> <u>NE/SE</u> <u>21</u> TOWNSHIP <u>18S</u> RANGE <u>28E</u> NMPM.
--

--

15. Elevation (Show whether DF, RT, GR, etc.)
3695 GR

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
--

NOTICE OF INTENTION TO:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:	
REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Start work 1-26-71

Spot 50 sk cement plug on bottom (TD 2208) through 2" EUE tubing using mud laden fluid as displacing medium.

Spot 25 sk cement plug at 1600' (Queen Sand)

Pull 8-1/4" casing (730')

*** Spot 25 sk cement plug @ ³²⁰~~370~~ (bottom of 10" casing) ²⁹⁰**

Place 10 sk cement plug in top of 10" casing and set 4-1/2" pipe marker.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Cliff Chapman **Cliff Chapman** TITLE Petroleum Engineer DATE 1/5/71

APPROVED BY W. A. Grossett TITLE OIL AND GAS INSPECTOR DATE JAN 7 1971

CONDITIONS OF APPROVAL, IF ANY: * as noted above